



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue
Costa Mesa, Ca. 92626
Phone (714) 426-0590 Fax (714) 426-0591

950-01015
FORD EXPEDITION
2003
REAR HITCH COVER

INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting (See Special Instructions For Paint Prep.) Parts that have been installed, preped, or painted are not returnable.

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Hitch Cover	1	Instruction Sheet	1	Street Scene Decal
		1	Urethane Prep Sheet		

TOOL LIST	
NONE	

1. The Street Scene hitch cover will need to be painted to match bumper color. Follow urethane painting parts surface preparation procedures.