



# STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

**950-09620**  
**1999 - 2004**  
**F-250 & F-350**  
**SUPER DUTY**  
**SINGLE WHEEL**  
**MUD FLAP**

## INSTALLATION INSTRUCTIONS

**VERY IMPORTANT !** Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	R.H. Mud Flap	1	Instruction Sheet	4	7/16" Nyloc Nuts
1	L.H. Mud Flap			4	7/16" Large Diameter Washers
4	7/16 X 1 1/2" Bolts			4	7/16" Small Diameter Washers

TOOL LIST	
Ratchet, Extension, 5/8" Socket, 5/8" Wrench, Safety Glasses	

1. Before beginning installation, be sure to wear proper eye protection.
2. Install R.H. mud flap next to frame aligning it with the two lower holes in the group of four holes to the rear of the tire.
3. Insert the small diameter 7/16" washer onto bolt and insert into the hole in frame. On the backside of frame install the larger washer and locknut. Do the same on the other bolt. Tighten snugly and re-align mud flap. Tighten to 60 lbs. Torque.
4. Do the same on the L.H. side.