



## STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue  
Costa Mesa, CA. 92626  
Phone (714) 426-0590 Fax (714) 426-0591

950-11120  
1988 - 1998 GM CK TRUCKS  
&  
1992-1999 SUBURBAN/TAHOE  
ELECTRIC  
CAL-VU MIRROR

### INSTALLATION INSTRUCTIONS

**NOTE:** Please check year, make, and model against application part number. Be sure both mirror heads and mounting plates are left & right side before painting. Parts that have been painted are not eligible for return.

**NOTE:** If Painting Mirrors Tape Over Threads To Keep Paint Off

**NOTE:** Check Your Mirror Plugs To Make Sure They Plug Into Your wire harness before painting, If painted warranty will be void.

**NOTE:** Mirrors are designed for specific year vehicles. Although mirror may appear to be the same, the electrical connectors will vary year to year. If your mirror does not plug into your factory wire harness, please check your part number and application guide.

**NOTE:** Do Not Use Loctite On Threads. Warranty Will Be Void If Used

**NOTE:** Do Not Attempt To Remove Glass For Paint Damage Could Occur And Glass Will Break.

**NOTE:** Do Not Over Tighten Nuts, Mounting Brackets Will Crack

**VERY IMPORTANT !** Read and understand all directions, then check the following parts list before starting installation.

PARTS LIST					
2	Mirror Heads	1	Instruction Sheet	6	Six mm Nuts
2	Mirror Plates	1	Street Scene Decal	2	Foam Rubber Strips

TOOL LIST	
Phillips screwdriver, 8mm combination wrench, 10mm combination wrench, door panel clip & trim pad removal tool GM part number : J 38778 or equivalent window crank removal tool GM part J 9886-01 or equivalent, manual windows only.	

### SECTION 1 88 - 94 GM CK TRUCK

1. Roll down windows and remove armrest screw using phillips screwdriver.
2. If equipped with manual windows, remove window crank with handle removal tool.
3. If equipped with power windows, remove Power Assist Control Panel using the panel removal tool. Lift from the front to detach clips.
4. Remove retaining clips from back of the three switches located on the Control Panel.

- 5 . Remove screw from behind panel and unplug wiring from Control Panel by releasing retaining clips.
- 6 . Using the GM Removal Tool, slide under edge of door panel and lift to pop off clip, move around panel with tool releasing all of the clips. Lift panel upward to remove.
- 7 . Remove nylon clips from inner door and reinstall onto door panel.
- 8 . Remove foam mirror access plug from door.
- 9 . Unplug wire harness connector, then remove stock mirror with 10 mm wrench.
- 10 . Install Cal-Vu mounting plates to mirror heads ( nuts provided ) using an 8 mm wrench. Install adhesive backed foam rubber strips to mounting plate. Align each strip with the mark located 3/4 inch from the bottom of the mirror plate, remove backing, then apply strip.
- 11 . Remove gasket from stock mirror plate and install on the Cal-Vu mirror. ( some trimming may be necessary for best fit. )
- 12 . Install Cal-Vu mirror using stock hardware, then plug in wire harness connector.
- 13 . Install foam mirror access plug into door.
- 14 . Install door panel by placing window seal portion of panel over door frame the lining clips up with holes. Use the palm of your hand to pop in place.
- 15 . On power windows equipped trucks, plug wiring into control panel, replace screw and pop panel into place. Install armrest screw.

## **SECTION II 95 - 97 GM CK TRUCK**

- 1 . Roll down windows and remove the mirror trim piece at the upper end of door panel. This is easily removed by using the panel removal tool to pop open the plastic retaining clip. Remove clip from inner door and replace onto trim piece.
- 2 . Remove foam mirror access plug from door.
- 3 . Unplug wire harness connector, then remove the three mounting 10 mm nuts which fasten the mirror to the door to remove mirrors.
- 4 . Install Cal-Vu mounting plates to mirror heads ( nuts provided ) using an 8 mm wrench.
- 5 . Install adhesive backed rubber strips to mounting plates. Align each strip with the mark located 3/4 inch from the bottom of the mirror plate, remove backing , then apply strip.
- 6 . Remove stock gaskets and install on your Cal-Vu mirrors.
- 7 . Install mirrors, tightening nuts fully, then plug in wire harness connector.
- 8 . Replace foam mirror access plug.
- 9 . Install trim piece by sliding the bottom in first and then snapping firmly at the top.