



# STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, CA. 92626

Phone (714) 426-0590 Fax (714) 426-0591

950-11126  
98 - 99 GM CK &  
CAD ESCALADE  
W / HEATED  
OEM MIRRORS  
CAL-VU MIRROR

## INSTALLATION INSTRUCTIONS

**NOTE:** Please check year, make, and model against application part number. Be sure both mirror heads and mounting plates are left & right side before painting. Parts that have been painted are not eligible for return.

**NOTE:** If Painting Mirrors Tape Over Threads To Keep Paint Off

**NOTE:** Check Your Mirror Plugs To Make Sure They Plug Into Your wire harness before painting, If painted warranty will be void.

**NOTE:** Mirrors are designed for specific year vehicles. Although mirror may appear to be the same, the electrical connectors will vary year to year. If your mirror does not plug into your factory wire harness, please check your part number and application guide.

**NOTE:** Do Not Use Loctite On Threads. Warranty Will Be Void If Used

**NOTE:** Do Not Attempt To Remove Glass For Paint Damage Could Occur And Glass Will Break.

**NOTE:** Do Not Over Tighten Nuts, Mounting Brackets Will Crack

**VERY IMPORTANT !** Read and understand all directions, then check the following parts list before starting installation.

PARTS LIST					
2	Mirror Heads	1	Instruction Sheet	6	Six mm Nuts
2	Mirror Plates	1	Street Scene Decal	2	Foam Rubber Strips

TOOL LIST	
8 mm combination wrench, 10 mm combination wrench, door panel clip & trim pad removal tool GM Part # J 38778 or equivalent.	

1. Roll down windows and remove the mirror trim piece at the upper end of door panel. This is easily removed by using the panel removal tool to pop open the plastic retaining clip. Remove clip from inner door and replace onto trim piece.
2. Remove foam mirror access plug from door.
3. Unplug wire harness connector and remove the three 10 mm mounting nuts which fasten the mirror to the door to remove mirrors.
4. Install Cal-Vu mounting plates to mirror heads ( nuts provided ) using a 8 mm wrench.
5. Install adhesive backed foam rubber strips to mounting plates. Align each strip with the mark located 3/4 inch from the bottom of the mirror plate, remove backing, then apply strips.
6. Remove stock gaskets and install on your Cal-Vu mirrors.
7. Install mirrors, tightening nuts fully, then plug in wire harness connector.
8. Replace foam mirror access plug.
9. Install trim piece by sliding the bottom in first, then snapping firmly at the top.