



## STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, CA. 92626

Phone (714) 426-0590 Fax (714) 426-0591

950-11310

GM " S " SERIES

82 - 93

CAL - Vu MIRROR

Drilling Required

### INSTALLATION INSTRUCTIONS

**NOTE:** Please check year, make, and model against application part number. Be sure both mirror heads and mounting plates are left & right side before painting. Parts that have been painted are not eligible for return.

**NOTE:** Do Not Use Loctite On Threads. Warranty Will Be Void If Used

**NOTE:** Do Not Attempt To Remove Glass For Paint Damage Could Occur And Glass Will Break.

**NOTE:** Do Not Over Tighten Nuts, Mounting Brackets Will Crack

**NOTE:** If Painting Mirrors Tape Over Threads To Keep Paint Off

**VERY IMPORTANT !** Read and understand all directions, then check the following parts list before starting installation.

PARTS LIST					
2	Mirror Heads	1	Instruction Sheet	12	6 mm Nuts
2	Mirror Plates	1	Street Scene Decal		

TOOL LIST	
drill motor, 9/32" drill bit, 3/4 hole saw, de-burring tool, ratchet, 6" extension, 10mm Socket, 8mm wrench, phillips screwdriver, door panel clip & trim pad removal tool GM part # J 38778 or equivalent window crank removal tool, GM part # 9886-01 or equivalent, manual applications only.	

1. Roll down windows and use phillips screwdriver to remove the three door pillar moulding screws.
2. Remove the two phillips screws located in the door pull cup. Slide armrest towards rear of vehicle to remove.
3. If equipped with manual windows, remove window crank with handle removal tool.
4. Using the panel removal tool, slide under front edge of door panel and lift to pop off clip, move around door panel with tool releasing all of the clips. Carefully lift panel upwards to remove.
5. Remove nylon clips from inner door and re-install onto door panel.
6. Remove stock mirror by removing mounting screws with phillips screwdriver.
7. Install Cal-Vu mounting plates to mirror heads ( nuts provided ) using 8mm wrench.
8. Drill all existing mirror mounting holes with 9/32" drill bit. Continue to drill all the way through the inner door frame, drill hole square and straight. Carefully drill 3/4" access holes from the interior side of the door with the hole saw. De-burr all holes. The door panel will cover access holes completely.
9. Install Cal-Vu mirrors ( nuts provided ) with 10mm socket and extension.
10. Install door panel by placing window seal portion of panel over door frame then lining clips up with holes. Use palm of your hand to pop clips into place.
11. Install remaining components in reverse order of disassembly.