



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

950-11510
DODGE RAM
1994 - 2001
CAL - Vu MIRROR

INSTALLATION INSTRUCTIONS

NOTE: Please check year, make, and model against application part number. Be sure both mirror heads and mounting plates are left & right side before painting. Parts that have been painted are not eligible for return.

NOTE: Do Not Use Loctite On Threads. Warranty Will Be Void If Used

NOTE: Do Not Attempt To Remove Glass For Paint Damage Could Occur And Glass Will Break.

NOTE: Do Not Over Tighten Nuts, Mounting Brackets Will Crack

NOTE: If Painting Mirrors Tape Over Threads To Keep Paint Off

VERY IMPORTANT ! Read and understand all directions, then check the following parts list before starting installation.

PARTS LIST					
2	Mirror Heads	1	Instruction Sheet	6	6 mm Nuts
2	Mirror Plates	1	Street Scene Decal		

TOOL LIST
Ratchet, 6" extension, phillips screwdriver, 10 mm socket wrench, flat blade screwdriver, door panel clip & trim pad removal tool * window crank removal tool, Manual windows only.

- 1 . Roll down windows, using a phillips screwdriver remove the two " door pull cup " screws as well as the retaining screw in the upper front corner of the door panel. Remove door pull cup.
- 2 . If equipped with power windows, remove Power Assist Panel. Release the rear retaining tab by depressing with a screwdriver through the pull cup opening. With the tab released lift the control panel from the rear and remove. Unplug the two connectors from Control Panel.
- 3 . If equipped with manual windows, remove window crank with handle removal tool.
- 4 . Using the Panel Removal Tool. Slide under front edge of door panel, lift to pop off clip, then move around panel with tool releasing all of the clips.
- 5 . Remove nylon clips from inner door and re-install onto door panel.
- 6 . Remove foam mirror plug.
- 7 . Remove stock mirror with 10 mm socket and extension.
- 8 . Install Cal-Vu mounting plates to mirror heads (nuts provided) using a 10 mm wrench.
- 9 . Install Cal-Vu mirror to vehicle using nuts provided, tightening nuts fully.
- 10 . Install foam mirror plug.
- 11 . Install door panel by lining clips up with holes. Use the palm of your hand to pop in place.
- 12 . On power window models. Plug in the two control connectors and pop in control panel.
- 13 . Install pull cup, then two retaining screws, and the door panel retaining screw.