



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, CA. 92626

Phone (714) 426-0590 Fax (714) 426-0591

950-11610
1997 - 2004
DODGE DAKOTA
1997 - 2003
DODGE DURANGO
CAL - Vu MIRROR

INSTALLATION INSTRUCTIONS

NOTE: Please check year, make, and model against application part number. Be sure both mirror heads and mounting plates are left & right side before painting. Parts that have been painted are not eligible for return.

NOTE: Do Not Use Loctite On Threads. Warranty Will Be Void If Used

NOTE: Do Not Attempt To Remove Glass For Paint Damage Could Occur And Glass Will Break.

NOTE: Do Not Over Tighten Nuts, Mounting Brackets Will Crack

NOTE: If Painting Mirrors Tape Over Threads To Keep Paint Off

VERY IMPORTANT ! Read and understand all directions, then check the following parts list before starting installation.

PARTS LIST

| | | | | | |
|---|---------------|---|--------------------|----|-----------|
| 2 | Mirror Heads | 1 | Instruction Sheet | 12 | 6 mm Nuts |
| 2 | Mirror Plates | 1 | Street Scene Decal | | |

TOOL LIST

3/8" ratchet, 6" extension, 8mm socket, small flat blade screwdriver, phillips screwdriver, 10mm wrench
30 torx socket, window crank removal tool, manual windows only.

1. Roll down windows and using a phillips head screwdriver remove the retaining screw in the upper front corner of the door panel. Remove the two #30 torx screws. One is located behind door release handle, the second is located behind the door pull handle. Remove phillips screw located at the rear bottom corner of door panel.
2. If equipped with power windows, remove Power Assist Control Panel. Insert the small screwdriver at top center of panel to release the top clip. Release bottom clip and remove panel. Unplug electrical connectors.
3. If equipped with manual windows, remove window crank with removal tool.
4. With palm of hand, gently tap door panel upward to release the integrated panel retaining clips. Lift up and remove door panel.
5. Remove stock mirror using an 8mm socket and extension. Remove foam gasket from back of stock mirror.
6. Install Cal-Vu mounting plates to mirror heads (nuts provided) using a 10mm wrench.
7. Place foam gasket over Cal-Vu mounting plate. Install Cal-Vu mirror to vehicle using stock hardware. Take care to keep foam gasket underneath edge of mirror plate.
8. Install door panel by lining up hooks on door panel with slots in door and sliding door panel down.
9. Install remaining components in reverse order of disassembly.