



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, CA. 92626

Phone (714) 426-0590 Fax (714) 426-0591

950-11710
FORD F - 150
1997 - 2003
CAL - Vu MIRROR

INSTALLATION INSTRUCTIONS

NOTE: Please check year, make, and model against application part number. Be sure both mirror heads and mounting plates are left & right side before painting. Parts that have been painted are not eligible for return.

NOTE: Do Not Use Loctite On Threads. Warranty Will Be Void If Used

NOTE: Do Not Attempt To Remove Glass For Paint Damage Could Occur And Glass Will Break.

NOTE: Do Not Over Tighten Nuts, Mounting Brackets Will Crack

NOTE: If Painting Mirrors Tape Over Threads To Keep Paint Off

VERY IMPORTANT ! Read and understand all directions, then check the following parts list before starting installation.

PARTS LIST					
2	Mirror Heads	1	Instruction Sheet	6	6 mm Nuts
2	Mirror Plates	1	Street Scene Decal		

TOOL LIST
3/8" Ratchet, 6" extension, 8 mm socket, 11 mm socket, small flat blade screwdriver, 10 mm wrench door panel clip & trim pad removal tool, window crank removal tool, manual windows only.

- 1 . Roll down windows and use a small flat blade screwdriver to remove the round plug beneath door handle. Remove the 8 mm bolt inside. Remove door release handle.
- 2 . Remove upper trim panels at front, to rear of door by grasping firmly with both hands and pulling upward from window side out.
- 3 . Remove the two plastic retainers now visible by pressing the center of retainer inward with a small screwdriver. Pry upward under edge of retainer housing to remove. Prepare retainers for re-assembly by pushing centers out of housings.
- 4 . If equipped with power windows, remove Power assist Control Panel. Gently pull upward to release retaining clips at front to rear of panel. Unplug the two connectors from the Control Panel.
- 5 . If equipped with manual windows, remove window crank with the removal tool.
- 6 . With palm of hand, gently tap door panel upward to release the integrated panel retaining clips. Lift up and remove door panel.
- 7 . Remove stock mirror with a 11 mm socket and extension. Remove foam gasket from back of stock mirror.
- 8 . Install Cal-Vu mounting plates to mirror heads (nuts provided) using a 10 mm wrench.
- 9 . Place foam gasket over Cal-Vu mounting plate. Install Cal-Vu mirror to vehicle using stock hardware. Take care to keep foam gasket underneath edge of mirror plate.
- 10 . Install door panel by lining up hooks on door panel with slots in door and sliding door panel down.
- 11 . Install two plastic retainers by pressing the retainer into door, then pushing center inward to lock retainer.
- 12 . Install remaining components in reverse order of disassembly.