



## STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, Ca. 92626

Phone (888) 477-0707 Fax (714) 426-0591

950-11820

93 - 2004

FORD RANGER

CAL - Vu MIRROR

### INSTALLATION INSTRUCTIONS

**NOTE:** Please check year, make, and model against application part number. Be sure both mirror heads and mounting plates are left & right side before painting. Parts that have been painted are not eligible for return.

**NOTE:** Check Your Mirror Plugs To Make Sure They Plug Into Your wire harness before painting, If painted warranty will be void.

**NOTE:** Mirrors are designed for specific year vehicles. Although mirror may appear to be the same, the electrical connectors will vary year to year. If your mirror does not plug into your factory wire harness, please check your part number and application guide.

**NOTE:** Do Not Use Loctite On Threads. Warranty Will Be Void If Used

**NOTE:** Do Not Attempt To Remove Glass For Paint Damage Could Occur And Glass Will Break.

**NOTE:** Do Not Over Tighten Nuts, Mounting Brackets Will Crack

**NOTE:** If Painting Mirrors Tape Over Threads To Keep Paint Off

**VERY IMPORTANT !** Read and understand all directions, then check the following parts list before starting installation.

#### PARTS LIST

2	Mirror Heads	1	Instruction Sheet	6	6 mm Nuts	
2	Mirror Plates	1	Street Scene Decal			

#### TOOL LIST

3/8" ratchet, 6" extension, 10mm socket, 11mm socket, # 20 torx socket, small flat blade screwdriver, phillips screwdriver.

1. Roll down windows then use a phillips head screwdriver to remove the three screws securing the door panel. One is located in the upper front corner, the second in the lower rear corner, and the third inside the door pull handle.
2. If equipped with manual windows, remove window crank handle by gently inserting small blade screw driver underneath the side of cover on handle. Pry gently upward to open cover. Remove the # 20 torx head screw.
3. If equipped with power windows, remove Power Assist Control Panel by grasping panel and pulling gently upward. Unplug electrical connectors.
4. With palm of hand, gently tap door panel upward to release the panel retaining hooks. Pull area below door release lever toward you and lift door panel up to remove.
5. Unplug wire harness connector, then remove stock mirror using a 11 mm socket and extension. Remove gasket from back of stock mirror.
6. Install Cal-Vu mounting plates to mirror heads ( nuts provided ) using a 10mm socket.
7. Place gasket over Cal-Vu mounting plate. Then install Cal-Vu mirror to vehicle using stock hardware. Plug in wire harness connector.
8. Install door panel by lining up hooks on door panel with slots in door and sliding door panel down.
9. Install remaining components in reverse order of disassembly.