



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

950-12113 & 12115

Mirror Glass

WITH

FRONT & REAR SIGNAL

WITH HEAT

INSTALLATION INSTRUCTIONS

NOTE: THIS IS OUR NEW STYLE GLASS IT WILL WORK WITH MOST OF OUR MIRRORS

NOTE: NEW GLASS WILL NOT FIT GLASS WITH BLACK RIM AROUND IT

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Left Side Glass	1	Instruction Sheet	6	# 4 X 1 1/4" Phillips Pan Screws
1	Right Side Glass				

TOOL LIST	
Flat Head Screwdriver, Phillips Head screwdriver Safety Glasses	

1. Take mirrors off of vehicle.
2. Pry off old glass off of GTM plate on mirror. Be sure to wear safety glasses to protect eyes.
3. In the center of mirror is the actuator " MOTOR " or " HANDSET " for manual mirrors. There are three screws in the center undo these.
4. Flip the actuator or handset over it will be fasten down to a (Black ABS Plate) with four screws undo these screws and discard these pieces.
5. Screw the actuator or handset back on the motor mounting plate with the screws provided.
6. If installing signal glass with heat you will need to plug in the signal wire and heater wires first before installaing glass.
7. Set new glass on the actuator or handset and push down in the center slightly till glass locks in place.

NOTE: DO NOT PRESS ON OUTER EDGES OF GLASS OR BREAKAGE MAY OCCUR