



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, CA. 92626

Phone (714) 426-0590 Fax (714) 426-0591

950-15110
88 - 98 GM TRUCKS
&
92-99 SUBURBANS
& TAHOES
CAL-VU MIRROR

INSTALLATION INSTRUCTIONS

NOTE: Please check year, make, and model against application part number. Be sure both mirror heads and mounting plates are left & right side before painting. Parts that have been painted are not eligible for return.

NOTE: Do Not Use Loctite On Threads. Warranty Will Be Void If Used

NOTE: Do Not Attempt To Remove Glass For Paint Damage Could Occur And Glass Will Break.

NOTE: Do Not Over Tighten Nuts, Mounting Brackets Will Crack

NOTE: If Painting Mirrors Tape Over Threads To Keep Paint Off

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
2	Mirror Heads	1	Instruction Sheet	6	Six mm Nuts
2	Mirror Plates	1	Street Scene Decal	2	Foam Rubber Strips

TOOL LIST	
Phillips screwdriver, 8mm combination wrench, 10mm combination wrench, door panel clip & trim pad removal tool GM part number : J 38778 or equivalent window crank removal tool GM part J 9886-01 or equivalent, manual windows only.	

SECTION 1 88 - 94 GM CK TRUCK

1. Roll down windows and remove armrest screw using phillips screwdriver.
2. If equipped with manual windows, remove window crank with handle removal tool.
3. If equipped with power windows, remove Power Assist Control Panel using the panel removal tool. Lift from the front to detach clips.
4. Remove retaining clips from back of the three switches located on the Control Panel.
5. Remove screw from behind panel and unplug wiring from Control Panel by releasing retaining clips.
6. Using the GM Removal Tool, slide under edge of door panel and lift to pop off clip, move around panel with tool releasing all of the clips. Lift panel upward to remove.
7. Remove nylon clips from inner door and reinstall onto door panel.
8. Remove foam mirror access plug from door.
9. Remove stock mirror with 10 mm wrench.

- 10 . Install Cal-Vu mounting plates to mirror heads (nuts provided) using an 8 mm wrench. Install adhesive backed foam rubber strips to mounting plate. Align each strip with the mark located 3/4 inch from the bottom of the mirror plate, remove backing, then apply strip.
- 11 . Remove gasket from stock mirror plate and install on the Cal-Vu mirror. (some trimming may be necessary for best fitment).
- 12 . Install Cal-Vu mirror using stock hardware.
- 13 . Install foam mirror access plug into door.
- 14 . Install door panel by placing window seal portion of panel over door frame the lining clips up with holes. Use the palm of your hand to pop in place.
- 15 . On power windows equipped trucks, plug wiring into control panel, replace screw and pop panel into place. Install armrest screw.

SECTION II 95 - UP GM CK TRUCK

- 1 . Roll down windows and remove the mirror trim piece at the upper end of door panel. This is easily removed by using the panel removal tool to pop open the plastic retaining clip. Remove clip from inner door and replace onto trim piece.
- 2 . Remove foam mirror access plug from door.
- 3 . Remove the three mounting 10 mm nuts which fasten the mirror to the door.
- 4 . Install Cal-Vu mounting plates to mirror heads (nuts provided) using an 8 mm wrench.
- 5 . Install adhesive backed rubber strips to mounting plates. Align each strip with the mark located 3/4 inch from the bottom of the mirror plate, remove backing , then apply strip.
- 6 . Remove stock gaskets and install on your Cal-Vu mirrors.
- 7 . Install mirrors, tightening fully.
- 8 . Replace foam mirror access plug.
- 9 . Install trim piece by sliding the bottom in first and then snapping firmly at the top.



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

CONNECTING STREET SCENE REAR SIGNAL

&

FRONT & REAR SIGNAL® MIRRORS

1988-1998 CHEV, GMC CK TRUCKS

1992-1999 SUBURBANS, TAHOES

& YUKONS & CREW CAB DUALY'S

CONNECTING STREET SCENE SIGNAL® MIRRORS

INSTRUCTIONS FOR PART NUMBERS

950-15110	950-17120	950-20120
950-15120	950-17126	950-25110
950-15126	950-18120	950-25120

1. Install Street Scene Signal® Mirrors assemblies to doors, following mirror installation instructions.
2. Before beginning electrical hook-up, check the operation of turn signals in the front and rear of vehical. If any problems exist, repair before wiring Street Scene Signal® Mirrors.
3. Remove the kick panels.
4. Run the Red / Black wire from the mirror into the door and thru the door boot. Run the right wire under the dash across to the steering column.
5. Run the left wire in the same way to below the steering column.
6. Remove the phillips head screws securing the panel beneath the steering column. This will expose the bundle of wires.
7. Locate the solid " LIGHT BLUE " wire. Turn the ignition key so that electrical power is on and activate the driver side turn signal. Probe the wire with a test light to verify that flashing turn signal is present. Label that wire as " Driver's Side Turn ". Locate the solid " DARK BLUE " wire and probe with test light. Activate the passenger side turn signal to verify that flashing turn signal power is present. Label that wire as " Passenger Side Turn ".
8. Make sure the harnesses are routed securly under the dash and enough slack is left for splicing.
9. Using the Quick Splice connector provided, splice the RED wire from the driver side harness into the " LIGHT BLUE " wire labeled " Driver's Side Turn ". Do not cut any wires when splicing, Splice the Red wire from the passenger side harness into the " DARK BLUE " wire labeled " Passenger Side Turn ".
10. Strip and twist together the ends of the " BLACK " wires from each harness. Crimp them together in the supplied ring connector and ground to a suitable nearby location on the metal frame work of the vehicle.
11. Activate each turn - signal to verify that the Street Scene Signal® Mirrors are working. Replace all the lower dash panels removed.
12. Re-install door panels.

10/12/04 Connecting Signal® Mirrors

1988 - 1998 Chevy / GMC CK trucks

1992 - 1999 Suburbans / Tahoes / Yukons & Crew Cab Dually's