



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, CA. 92626

Phone (714) 426-0590 Fax (714) 426-0591

950-15710
FORD F - 150
1997 - 2003
CAL - Vu MIRROR

INSTALLATION INSTRUCTIONS

NOTE: Please check year, make, and model against application part number. Be sure both mirror heads and mounting plates are left & right side before painting. Parts that have been painted are not eligible for return.

NOTE: Do Not Use Loctite On Threads. Warranty Will Be Void If Used

NOTE: Do Not Attempt To Remove Glass For Paint Damage Could Occur And Glass Will Break.

NOTE: Do Not Over Tighten Nuts, Mounting Brackets Will Crack

NOTE: If Painting Mirrors Tape Over Threads To Keep Paint Off

VERY IMPORTANT ! Read and understand all directions, then check the following parts list before starting installation.

PARTS LIST					
2	Mirror Heads	1	Instruction Sheet	6	6 mm Nuts
2	Mirror Plates	1	Street Scene Decal		

TOOL LIST
3/8" Ratchet, 6" extension, 8 mm socket, 11 mm socket, small flat blade screwdriver, 10 mm wrench door panel clip & trim pad removal tool, window crank removal tool, manual windows only.

- 1 . Roll down windows and use a small flat blade screwdriver to remove the round plug beneath door handle. Remove the 8 mm bolt inside. Remove door release handle.
- 2 . Remove upper trim panels at front, to rear of door by grasping firmly with both hands and pulling upward from window side out.
- 3 . Remove the two plastic retainers now visible by pressing the center of retainer inward with a small screwdriver. Pry upward under edge of retainer housing to remove. Prepare retainers for re-assembly by pushing centers out of housings.
- 4 . If equipped with power windows, remove Power assist Control Panel. Gently pull upward to release retaining clips at front to rear of panel. Unplug the two connectors from the Control Panel.
- 5 . If equipped with manual windows, remove window crank with the removal tool.
- 6 . With palm of hand, gently tap door panel upward to release the integrated panel retaining clips. Lift up and remove door panel.
- 7 . Remove stock mirror with a 11 mm socket and extension. Remove foam gasket from back of stock mirror.
- 8 . Install Cal-Vu mounting plates to mirror heads (nuts provided) using a 10 mm wrench.
- 9 . Place foam gasket over Cal-Vu mounting plate. Install Cal-Vu mirror to vehicle using stock hardware. Take care to keep foam gasket underneath edge of mirror plate.
- 10 . Install door panel by lining up hooks on door panel with slots in door and sliding door panel down.
- 11 . Install two plastic retainers by pressing the retainer into door, then pushing center inward to lock retainer.
- 12 . Install remaining components in reverse order of disassembly.



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

**CONNECTING
STREET SCENE
SIGNAL® MIRRORS
1997 - 2000
FORD F-150**

CONNECTING STREET SCENE SIGNAL® MIRRORS

INSTRUCTIONS FOR PART NUMBERS

950-15710	950-15730	950-17730
950-15720	950-17720	950-18720
950-15726	950-17726	950-20720

1. Install Street Scene Signal® Mirror assemblies to doors following mirror installation instruction.
2. Before beginning electrical hook - up check the operation of turn signals in the front and rear of vehicle. If any problem exist, repair before installing Street Scene Signal® Mirrors.
3. Run the Black / Red wire from the mirror into the door and into the rubber boot. Pull the rubber boot out between the door and door frame. Pass the wire harness into the vehicle by going through the opening located by the rubber boot. Run the wire to the left of the steering column. Do the same on the other side of truck. Re-install rubber boots.
4. The electrical wiring for the turn aignal switch is located under the dash just below and left of the steering column. Locate the **GREEN WITH WHITE STRIPE** wire from within the wire bundle. Turn the ignition key so that the electrical power is on and activate the driver side turn signal. Probe the wire with the test light to verify that flashing turn signal power is present. Label that wire as "**Driver Side Turn**". Locate the **WHITE WITH BLUE STRIPE** wire withing the wire bundle. Activate the passenger side turn signal and probe the wire with the test light to verify that flashing turn signal power is present. Label that wire as "**Passenger Side Turn**".
5. Make sure the harnesses are routed securely under the dash and enough slack is left for splicing.
6. Splice the **RED** wire from the passenger side harness into the **WHITE WITH BLUE STRIPE** wire previously labeled "**Passenger Side Turn**". Do not cut any wires when splicing.
7. Splice the **RED** wire from the driver side harness into the "**GREEN WITH WHITE STRIPE**" wire previously labeled "**Drivers Side Turn**".
8. Strip andf twist together the ends of the black wires from each harness. Crimp them together in the supplied ring connector and ground to a suitable nearby location on the metal framework of the vehicle. A good ground location is located on the bare metal plate behind the hood release lever.
9. Activate each turn signal to verify that the Street Scene Signal® Mirrors are working.