



# STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, CA. 92626

Phone (714) 426-0590 Fax (714) 426-0591

**950-15910**  
**99 - 2004 Chev Silverado**  
**&**  
**99 - 2004 GMC Sierra**  
**CAL-VU MIRROR**

## INSTALLATION INSTRUCTIONS

**NOTE: Please check year, make, and model against application part number. Be sure both mirror heads and mounting plates are left & right side before painting. Parts that have been painted are not eligible for return.**

**NOTE: Do Not Use Loctite On Threads. Warranty Will Be Void If Used**

**NOTE: Do Not Attempt To Remove Glass For Paint Damage Could Occur And Glass Will Break.**

**NOTE: Do Not Over Tighten Nuts, Mounting Brackets Will Crack**

**NOTE: If Painting Mirrors Tape Over Threads To Keep Paint Off**

**VERY IMPORTANT !** Read and understand all directions, then check the following parts list before starting installation.

PARTS LIST					
<b>2</b>	Mirror Heads	<b>1</b>	Instruction Sheet	<b>6</b>	Six mm Nuts
<b>2</b>	Mirror Plates	<b>1</b>	Street Scene Decal		

TOOL LIST
Phillips screwdriver, 8mm combination wrench, 10mm combination wrench, door panel clip & trim pad removal tool GM part number : J 38778 or equivalent window crank removal tool GM part J 9886-01 or equivalent, manual windows only.

1. Roll down windows and remove the mirror trim piece at the upper end of door panel. This is easily removed by using the panel removal tool to pop open the plastic retaining clip. Remove clip from inner door and replace onto trim piece.
2. Remove foam mirror access plug from door.
3. Remove the three mounting 10 mm nuts which fasten the mirror to the door to remove mirrors.
4. Install Cal-Vu mounting plates to mirror heads ( nuts provided ) using an 8 mm wrench.
5. Remove stock gaskets and install on your Cal-Vu mirrors.
6. Install mirrors, tightening nuts fully.
7. Replace foam mirror access plug.
8. Install trim piece by sliding the bottom in first and then snapping firmly at the top.



# STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue  
Costa Mesa, CA. 92626

Phone (714) 426-0590 Fax (714) 426-0591

950-15910  
Chev Silverado  
2004 - 2005  
GMC Sierra  
CAL-VU MIRROR

## INSTALLATION INSTRUCTIONS

**NOTE:** Please check year, make, and model against application part number. Be sure both mirror heads and mounting plates are left & right side before painting. Parts that have been painted are not eligible for return.

**NOTE:** Check Your Mirror Plugs To Make Sure They Plug Into Your wire harness before painting, If painted warranty will be void.

**NOTE:** Mirrors are designed for specific year vehicles. Although mirror may appear to be the same, the electrical connectors will vary year to year. If your mirror does not plug into your factory wire harness, please check your part number and application guide.

**NOTE:** Do Not Use Loctite On Threads. Warranty Will Be Void If Used

**NOTE:** Do Not Attempt To Remove Glass For Paint Damage Could Occur And Glass Will Break.

**NOTE:** Do Not Over Tighten Nuts, Mounting Brackets Will Crack

**NOTE:** If Painting Mirrors Tape Over Threads To Keep Paint Off

**VERY IMPORTANT !** Read and understand all directions, then check the following parts list before starting installation.

PARTS LIST					
2	Mirror Heads	1	Instruction Sheet	6	Six mm Nuts
2	Mirror Plates	1	Street Scene Decal		

TOOL LIST
10 MM Socket, 7 MM Socket, 5 MM Socket, 11 MM Socket, Ratchet, Extension, Flat Blade Screwdriver, # 20 Torx

1. Roll down windows prior to removing door panels.
2. Remove the bezel surrounding the manual door lock, located in the center of door panel just below the door glass. Remove the screw located behind it. NOTE: direction of manual door lock.
3. Remove the hex head screw located in the arm rest portion of the door panel.
4. Remove the bezel surrounding the door release handle.
5. On late 2004 models and 2005 models, remove the round plastic cover over the # 20 torx screw located at the outer center edge of door panel and then remove screw. Pry out the push in fastener across the panel at the front edge. Be careful not to damage the fasteners for use when reassembling.
6. Lift up on door panel to remove, while reaching in from behind and disconnecting courtesy light.
7. Peel back the upper corner of the plastic protector below the mirror on door.
8. Remove the foam filler located in the triangular opening behind mirror.
9. Remove the three attaching nuts and remove mirror. Save nuts for re-assembly.
10. Remove gasket from OEM mirror and install on Street Scene Mirror.
11. Install mirror in reverse order of removal.



## STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

**CONNECTING  
STREET SCENE  
SIGNAL® MIRRORS**  
1999-2002 SILVERADO / SIERRA  
2000-2002 SUBURBAN/YUKON/TAHOE

### CONNECTING STREET SCENE SIGNAL® MIRRORS

INSTRUCTIONS FOR PART NUMBERS		
950-15910	950-17920	950-20920
950-15920	950-18920	950-25910
950-17925	950-19920	

1. Install Street scene Signal® Mirrors to doors following mirror installation instructions.
2. Before beginning electric hook-up, check the operation of turn signals in the front and rear of vehicle. If any problem exist repair before installing Street Scene Signal® mirrors.
3. Remove the door sill plates and kick panels.
4. Run the **RED / BLACK** harness wire from the mirror into the door. Pull out the rubber boot from the door and door frame. Guide the wire harness out of the hole vacated by the rubber boot.
5. Pull the rubber boot from the door frame. Guide the wire through the rubber boot and into the vehicle. Replace the rubber boot between the door and door frame.
6. Do the same on the passenger side. Run the wire across the dash to beneath the steering column.
7. The electrical wiring for the turn signals is located to the left of the steering column.
8. Locate the **LIGHT BLUE** wire from the wire bundle. Turn ignition key so that the electrical power is on activate the driver side turn signal. Probe the wire with the test light ti verify that flashing turn signal power is present. Label that wire as "**Drivers Side Turn**". Locate the **DARK BLUE** wire from within the wire bundle. Activate the passenger side turn signal and probe the wire with the test light to verify that flashing turn signal power is present. Label that wire as " Passenger Side Turn ".
9. Make sure the harnesses are routed securely under the dash and enough slack is left for splicing.
10. Splice the **RED** wire from the drivers side harness into the **LIGHT BLUE** wire previously labeled "**Drivers Side Turn**".
11. Splice the **RED** wire from the passenger side harness into the **DARK BLUE** wire previously labeled "**Passengers Side Turn**".
12. Strip and twist together the ends of the **BLACK** wires from each harness. Crimp them together in the supplied ring connector and ground to a suitable location on the metal framework of the vehicle.
13. Activate each turn signal to verify that the Street Scene Signal® Mirrors are working.

1/12/01 Connecting Street Scene Signal® Mirrors  
1999 - 2002 Silverado / Sierra  
2000 - 2002 Suburban / Yukon / Tahoe



## STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

**CONNECTING  
STREET SCENE  
SIGNAL® MIRRORS  
2003 - 2004  
GM SIERRA & SILVERADO  
TRUCKS, YUKONS, SUBURBAN**

### CONNECTING STREET SCENE SIGNAL® MIRRORS

INSTRUCTIONS FOR PART NUMBERS		
950-15910	950-17930	950-27922
950-15925	950-25910	950-27930
950-17922	950-25925	

1. Install Street Scene Signal® Mirrors to doors following mirror installation instructions.
2. Before beginning electrical hook-up check operation of turn signals in the front and rear of vehicle. If any problems exist repair BEFORE installing Street Scene Signal® Mirrors.
3. Electrical hook ups are located at the wiring harness in each door. Locate the main harness ( Large Black plug with grey pivot arm).
4. Starting in the Driver's side door, locate the LIGHT BLUE wire and probe with test light to verify that flashing turn signal power is present. Deactivate the turn signal and depress the brake to make sure you have not located the rear turn wire. Label that wire as " Front Driver Side Turn ". Next in the passenger side door locate the DARK BLUE wire and probe with test light to verify that flashing turn signal power is present. Deactivate the turn signal and depress the brake to make sure you have not located the rear turn wire. Label that wire as " Front Passenger Side Turn ". NOTE: Triple check to ensure you have the correct signal wire as there are several of them to check from.
5. Make sure the harnesses are routed securely and enough slack is left for splicing. Split and cut the Signal® Mirror harness to length.
6. Strip the black wire and crimp the yellow grounding ring. Using a 10MM socket, wrench, remove the bolt by the speaker. NOTE: Make sure to scrape any paint so that you get a good ground. Attach the grounding ring to the bolt and tighten the bolt in place.
7. Splice the RED wire from the driver's side harness into the LIGHT BLUE wire previously labeled " Driver's Side Turn". Splice the RED wire from the passenger side harness into the Dark Blue wire previously labeled " Passenger Side Turn". Activate each turn signal to verify that the Signal® Mirrors are working.
8. Replace any door accessories, door panels, Etc.