



**STREET SCENE EQUIPMENT, INC.**

365 McCormick Avenue

Costa Mesa, CA. 92626

Phone (714) 426-0590 Fax (714) 426-0591

950-16445  
**ASTRO VAN & SAFARI**  
 1999 - 2000  
**ELEC. MIRRORS**  
**W / FACTORY HEATED GLASS**

**INSTALLATION INSTRUCTIONS**

**NOTE:** Please check year, make, and model against application part number. Be sure both mirror heads and mounting plates are left & right side before painting. Parts that have been painted are not eligible for return.

**NOTE:** Check Your Mirror Plugs To Make Sure They Plug Into Your wire harness before painting, If painted warranty will be void.

**NOTE:** Mirrors are designed for specific year vehicles. Although mirror may appear to be the same, the electrical connectors will vary year to year. If your mirror does not plug into your factory wire harness, please check your part number and application guide.

**NOTE:** Do Not Use Loctite On Threads. Warranty Will Be Void If Used

**NOTE:** Do Not Attempt To Remove Glass For Paint Damage Could Occur And Glass Will Break.

**NOTE:** Do Not Over Tighten Nuts, Mounting Brackets Will Crack

**VERY IMPORTANT !** Read and understand all directions, then check the following parts list before starting installation. Installation time is approximately 20 minutes.

| <b>PARTS LIST</b> |               |          |                    |          |                        |
|-------------------|---------------|----------|--------------------|----------|------------------------|
| <b>2</b>          | Mirror Heads  | <b>1</b> | Instruction Sheet  | <b>6</b> | 6 mm Nuts              |
| <b>2</b>          | Mirror Plates | <b>1</b> | Street Scene Decal | <b>1</b> | Got Street Scene Decal |

| <b>TOOL LIST</b>   |
|--|
| Ratchet, 6" Extension, 10 mm Socket, Door Panel Clip & Trim Pad Removal Tool GM Part Number J 38778 Or Equivalent. |

1. Roll down windows and remove mirror trim oanel by first inserting Panel Removal Tool underneath the rear portion of the panel two inches from the top. Pry upwards to release clip. Pull top of panel towards you to release bottom clip from door panel.
2. Remove foam mirror access plug from door.
3. Unplug wire harness connector and remove stock mirror with 10 mm socket and extension.
4. Install Cal-Vu mounting plates to mirror heads ( nuts provided ) using 10 mm socket.
5. Remove gaskets from stock mirrors and install onto Cal-Vu mounting plates.
6. Install Cal-Vu mirror to vehicle using stock hardware, tightening nuts fully, then plug in wire harness connector.
7. Install foam mirror access plug into door.
8. Install mirror trim panel by first inserting tab on the panel bottom into the slot on the door panel, then rotate panel upwards to engage the top clip. Use the palm of your hand to pop clip in place fully.

