



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue
Costa Mesa, CA. 92626
Phone (714) 426-0590 Fax (714) 426-0591

950-17126
98 - 99 GM CK &
CAD ESCALADE
ELECTRIC CAL-Vu MIRRORS
WITH FACTORY HEATED
GLASS & REAR SIGNAL
CONVERSION KIT

INSTALLATION INSTRUCTIONS

NOTE: Please check year, make, and model against application part number. Be sure both mirror heads and mounting plates are left & right side before painting. Parts that have been painted are not eligible for return.

NOTE: If Painting Mirrors Tape Over Threads To Keep Paint Off

NOTE: Check Your Mirror Plugs To Make Sure They Plug Into Your wire harness before painting, If painted warranty will be void.

NOTE: Mirrors are designed for specific year vehicles. Although mirror may appear to be the same, the electrical connectors will vary year to year. If your mirror does not plug into your factory wire harness, please check your part number and application guide.

NOTE: Do Not Use Loctite On Threads. Warranty Will Be Void If Used

NOTE: Do Not Attempt To Remove Glass For Paint Damage Could Occur And Glass Will Break.

NOTE: Do Not Over Tighten Nuts, Mounting Brackets Will Crack

VERY IMPORTANT ! Read and understand all directions, then check the following parts list before starting installation.

PARTS LIST					
2	Mirror Heads	1	Instruction Sheet	6	Six mm Nuts
2	Mirror Plates	1	Street Scene Decal	2	Foam Rubber Strips

TOOL LIST
8 mm combination wrench, 10 mm combination wrench, door panel clip & trim pad removal tool GM Part # J 38778 or equivalent.

1. Roll down windows and remove the mirror trim piece at the upper end of door panel. This is easily removed by using the panel removal tool to pop open the plastic retaining clip. Remove clip from inner door and replace onto trim piece.
2. Remove foam mirror access plug from door.
3. Unplug wire harness connector and remove the three 10 mm mounting nuts which fasten the mirror to the door to remove mirrors.
4. Install Cal-Vu mounting plates to mirror heads (nuts provided) using a 8 mm wrench.
5. Install adhesive backed foam rubber strips to mounting plates. Align each strip with the mark located 3/4 inch from the bottom of the mirror plate, remove backing, then apply strips.
6. Remove stock gaskets and install on your Cal-Vu mirrors.
7. Install mirrors, tightening nuts fully, then plug in wire harness connector.
8. Replace foam mirror access plug.
9. Install trim piece by sliding the bottom in first, then snapping firmly at the top.



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue
Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

**CONNECTING
STREET SCENE
SIGNAL® MIRRORS**

1988-1998 CHEV, GMC CK TRUCKS
1992-1999 SUBURBANS, TAHOES
& YUKONS & CREW CAB DUALY'S

CONNECTING STREET SCENE SIGNAL® MIRRORS

INSTRUCTIONS FOR PART NUMBERS		
950-15110	950-17120	950-18120
950-15120	950-17126	950-20120
950-15126		

1. Install Street Scene Signal® Mirrors assemblies to doors, following mirror installation instructions.
2. Before beginning electrical hook-up, check the operation of turn signals in the front and rear of vehical. If any problems exist, repair before wiring Street Scene Signal® Mirrors.
3. Remove the kick panels.
4. Run the Red / Black wire from the mirror into the door and thru the door boot. Run the right wire under the dash across to the steering column.
5. Run the left wire in the same way to below the steering column.
6. Remove the phillips head screws securing the panel beneath the steering column. This will expose the bundle of wires.
7. Locate the solid " LIGHT BLUE " wire. Turn the ignition key so that electrical power is on and activate the driver side turn signal. Probe the wire with a test light to verify that flashing turn signal is present. Label that wire as " Driver's Side Turn ". Locate the solid " DARK BLUE " wire and probe with test light. Activate the passenger side turn signal to verify that flashing turn signal power is present. Label that wire as " Passenger Side Turn ".
8. Make sure the harnesses are routed securly under the dash and enough slack is left for splicing.
9. Using the Quick Splice connector provided, splice the RED wire from the driver side harness into the " LIGHT BLUE " wire labeled " Driver's Side Turn ". Do not cut any wires when splicing, Splice the Red wire from the passenger side harness into the " DARK BLUE " wire labeled " Passenger Side Turn ".
10. Strip and twist together the ends of the " BLACK " wires from each harness. Crimp them together in the supplied ring connector and ground to a suitable nearby location on the metal frame work of the vehicle.
11. Activate each turn - signal to verify that the Street Scene Signal® Mirrors are working. Replace all the lower dash panels removed.
12. Re-install door panels.

1/11/01 Connecting Signal® Mirrors
1988 - 1998 Chevy / GMC CK trucks
1992 - 1999 Suburbans / Tahoes / Yukons & Crew Cab Dually's