



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, CA. 92626

Phone (714) 426-0590 Fax (714) 426-0591

950-17925

99 - 2002 Chev Silverado

&

99 - 2002 GMC Sierra

& SUBURBAN

W / FACTORY HEATED GLASS

& REAR SIGNAL

CONVERSION KIT

INSTALLATION INSTRUCTIONS

NOTE: Please check year, make, and model against application part number. Be sure both mirror heads and mounting plates are left & right side before painting. Parts that have been painted are not eligible for return.

NOTE: Check Your Mirror Plugs To Make Sure They Plug Into Your wire harness before painting, If painted warranty will be void.

NOTE: Mirrors are designed for specific year vehicles. Although mirror may appear to be the same, the electrical connectors will vary year to year. If your mirror does not plug into your factory wire harness, please check your part number and application guide.

NOTE: Do Not Use Loctite On Threads. Warranty Will Be Void If Used

NOTE: Do Not Attempt To Remove Glass For Paint Damage Could Occur And Glass Will Break.

NOTE: Do Not Over Tighten Nuts, Mounting Brackets Will Crack

NOTE: If Painting Mirrors Tape Over Threads To Keep paint Off

VERY IMPORTANT ! Read and understand all directions, then check the following parts list before starting installation.

PARTS LIST

2	Mirror Heads	1	Instruction Sheet	6	Six mm Nuts
2	Mirror Plates	1	Street Scene Decal		

TOOL LIST

Phillips screwdriver, 8mm combination wrench, 10mm combination wrench, door panel clip & trim pad removal tool GM part number : J 38778 or equivalent window crank removal tool GM part J 9886-01 or equivalent, manual windows only.

1. Roll down windows and remove the mirror trim piece at the upper end of door panel. This is easily removed by using the panel removal tool to pop open the plastic retaining clip. Remove clip from inner door and replace onto trim piece.
2. Remove foam mirror access plug from door.
3. Unplug wire harness connector, then remove the three mounting 10 mm nuts which fasten the mirror to the door to remove mirrors.
4. Install Cal-Vu mounting plates to mirror heads (nuts provided) using an 8 mm wrench.
5. Remove stock gaskets and install on your Cal-Vu mirrors.
6. Install mirrors, tightening nuts fully, then plug in wire harness connector.
7. Replace foam mirror access plug.
8. Install trim piece by sliding the bottom in first and then snapping firmly at the top.



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue
Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

CONNECTING STREET SCENE SIGNAL® MIRRORS

1999-2001 SILVERADO / SIERRA
2000-2001 SUBURBAN/YUKON/TAHOE

CONNECTING STREET SCENE SIGNAL® MIRRORS

INSTRUCTIONS FOR PART NUMBERS

950-15910	950-17920	950-20920
950-15920	950-18920	
950-17925	950-19920	

1. Install Street scene Signal® Mirrors to doors following mirror installation instructions.
2. Before beginning electric hook-up, check the operation of turn signals in the front and rear of vehicle. If any problem exist repair before installing Street Scene Signal® mirrors.
3. Remove the door sill plates and kick panels.
4. Run the **RED / BLACK** harness wire from the mirror into the door. Pull out the rubber boot from the door and door frame. Guide the wire harness out of the hole vacated by the rubber boot.
5. Pull the rubber boot from the door frame. Guide the wire through the rubber boot and into the vehicle. Replace the rubber boot between the door and door frame.
6. Do the same on the passenger side. Run the wire across the dash to beneath the steering column.
7. The electrical wiring for the turn signals is located to the left of the steering column.
8. Locate the **LIGHT BLUE** wire from the wire bundle. Turn ignition key so that the electrical power is on activate the driver side turn signal. Probe the wire with the test light to verify that flashing turn signal power is present. Label that wire as "**Drivers Side Turn**". Locate the **DARK BLUE** wire from within the wire bundle. Activate the passenger side turn signal and probe the wire with the test light to verify that flashing turn signal power is present. Label that wire as "**Passenger Side Turn**".
9. Make sure the harnesses are routed securely under the dash and enough slack is left for splicing.
10. Splice the **RED** wire from the drivers side harness into the **LIGHT BLUE** wire previously labeled "**Drivers Side Turn**".
11. Splice the **RED** wire from the passenger side harness into the **DARK BLUE** wire previously labeled "**Passengers Side Turn**".
12. Strip and twist together the ends of the **BLACK** wires from each harness. Crimp them together in the supplied ring connector and ground to a suitable location on the metal framework of the vehicle.
13. Activate each turn signal to verify that the Street Scene Signal® Mirrors are working.

1/12/01 Connecting Street Scene Signal® Mirrors

1999 - 2001 Silverado / Sierra

2000 - 2001 Suburban / Yukon / Tahoe