



# STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue  
Costa Mesa, CA. 92626  
Phone (714) 426-0590 Fax (714) 426-0591

950-17930  
2003 Chev Silverado  
&  
2003 GMC Sierra  
ELECTRIC CAL-Vu MIRROR  
W / FACTORY HEATED GLASS  
& REAR SIGNAL  
CONVERSION KIT

## INSTALLATION INSTRUCTIONS

**NOTE:** Please check year, make, and model against application part number. Be sure both mirror heads and mounting plates are left & right side before painting. Parts that have been painted are not eligible for return.

**NOTE:** Check Your Mirror Plugs To Make Sure They Plug Into Your wire harness before painting, If painted warranty will be void.

**NOTE:** Mirrors are designed for specific year vehicles. Although mirror may appear to be the same, the electrical connectors will vary year to year. If your mirror does not plug into your factory wire harness, please check your part number and application guide.

**NOTE:** Do Not Use Loctite On Threads. Warranty Will Be Void If Used

**NOTE:** Do Not Attempt To Remove Glass For Paint Damage Could Occur And Glass Will Break.

**NOTE:** Do Not Over Tighten Nuts, Mounting Brackets Will Crack

**NOTE:** If Painting Mirrors Tape Over Threads To Keep Paint Off

**VERY IMPORTANT !** Read and understand all directions, then check the following parts list before starting installation.

PARTS LIST					
2	Mirror Heads	1	Instruction Sheet	6	Six mm Nuts
2	Mirror Plates	1	Street Scene Decal		

TOOL LIST	
10 MM Socket, 7 MM Socket, 5 MM Socket, 11 MM Socket, Ratchet, Extension, Flat Blade Screwdriver	

1. Roll down windows prior to removing door panels.
2. Remove the bezel surrounding the manual door lock, located in the center of door panel just below the door glass. Remove the screw located behind it. NOTE: direction of manual door lock.
3. Remove the hex head screw located in the arm rest portion of the door panel.
4. Remove the bezel surrounding the door release handle.
5. Lift up on door panel to remove, while reaching in from behind and disconnecting courtesy light.
6. Disconnect mirror plugs, blue and black by depressing the locking tabs. It is not necessary to remove the door panel from vehicle. If you would like to remove the door panel completely disconnect the other plugs. The larger black plug requires the grey arm on it to be released and pulled back in an arc like fashion.
7. Peel back the upper corner of the plastic protector below the mirror on door.
8. Unsnap the mirror wire retainers from doors.
9. Remove the foam filler located in the triangular opening behind mirror.
10. Remove the three attaching nuts and remove mirror. Save nuts for re-assembly.
11. Remove gasket from OEM mirror and install on Street Scene Mirror.
12. Install mirror in reverse order of removal.



## STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue  
Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

**CONNECTING  
STREET SCENE  
SIGNAL® MIRRORS  
2003 - 2004  
GM SIERRA & SILVERADO  
TRUCKS, YUKONS, SUBURBAN**

### CONNECTING STREET SCENE SIGNAL® MIRRORS

INSTRUCTIONS FOR PART NUMBERS		
950-15910	950-17930	950-27922
950-15925	950-25910	950-27930
950-17922	950-25925	

1. Install Street Scene Signal® Mirrors to doors following mirror installation instructions.
2. Before beginning electrical hook-up check operation of turn signals in the front and rear of vehicle. If any problems exist repair BEFORE installing Street Scene Signal® Mirrors.
3. Electrical hook ups are located at the wiring harness in each door. Locate the main harness ( Large Black plug with grey pivot arm).
4. Starting in the Driver's side door, locate the LIGHT BLUE wire and probe with test light to verify that flashing turn signal power is present. Deactivate the turn signal and depress the brake to make sure you have not located the rear turn wire. Label that wire as " Front Driver Side Turn ". Next in the passenger side door locate the DARK BLUE wire and probe with test light to verify that flashing turn signal power is present. Deactivate the turn signal and depress the brake to make sure you have not located the rear turn wire. Label that wire as " Front Passenger Side Turn ". NOTE: Triple check to ensure you have the correct signal wire as there are several of them to check from.
5. Make sure the harnesses are routed securely and enough slack is left for splicing. Split and cut the Signal® Mirror harness to length.
6. Strip the black wire and crimp the yellow grounding ring. Using a 10MM socket, wrench, remove the bolt by the speaker. Attach the grounding ring to the bolt and tighten the bolt in place.
7. Splice the RED wire from the driver's side harness into the LIGHT BLUE wire previously labeled " Driver's Side Turn". Splice the RED wire from the passenger side harness into the Dark Blue wire previously labeled " Passenger Side Turn". Activate each turn signal to verify that the Signal® Mirrors are working.
8. Replace any door accessories, door panels, Etc.