



## STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

### CONNECTING STREET SCENE FRONT & REAR FACE SIGNAL® MIRRORS

1988-1998 CHEV, GMC CK TRUCKS

1992-1999 SUBURBANS, TAHOES

& YUKONS & CREW CAB DUALY'S

## CONNECTING STREET SCENE SIGNAL® MIRRORS

### INSTRUCTIONS FOR PART NUMBERS

950-15110	950-17120	950-20120
950-15120	950-17126	950-25110
950-15126	950-18120	950-25120

1. Install Street Scene Signal ® Mirrors assemblies to doors, following mirror installation instructions.
2. Before beginning electrical hook-up, check the operation of turn signals in the front and rear of vehical. If any problems exist, repair before wiring Street Scene Signal ® Mirrors.
3. Remove the kick panels.
4. Run the Red / Black wire from the mirror into the door and thru the door boot. Run the right wire under the dash across to the steering column.
5. Run the left wire in the same way to below the steering column.
6. Remove the phillips head screws securing the panel beneath the steering column. This will expose the bundle of wires.
7. Locate the solid " LIGHT BLUE " wire. Turn the ignition key so that electrical power is on and activate the driver side turn signal. Probe the wire with a test light to verify that flashing turn signal is present. Label that wire as " Driver's Side Turn ". Locate the solid " DARK BLUE " wire and probe with test light. Activate the passenger side turn signal to verify that flashing turn signal power is present. Label that wire as " Passenger Side Turn ".
8. Make sure the harnesses are routed securly under the dash and enough slack is left for splicing.
9. Using the Quick Splice connector provided, splice the RED wire from the driver side harness into the " LIGHT BLUE " wire labeled " Driver's Side Turn ". Do not cut any wires when splicing, Splice the Red wire from the passenger side harness into the " DARK BLUE " wire labeled " Passenger Side Turn ".
10. Strip and twist together the ends of the " BLACK " wires from each harness. Crimp them together in the supplied ring connector and ground to a suitable nearby location on the metal frame work of the vehicle.
11. Activate each turn - signal to verify that the Street Scene Signal ® Mirrors are working. Replace all the lower dash panels removed.
12. Re-install door panels.

1/11/01 Connecting Signal® Mirrors

1988 - 1998 Chevy / GMC CK trucks

1992 - 1999 Suburbans / Tahoes / Yukons & Crew Cab Dually's