



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

**CONNECTING
STREET SCENE
SIGNAL® MIRRORS
1997 - 2000
FORD F-150**

CONNECTING STREET SCENE SIGNAL® MIRRORS

INSTRUCTIONS FOR PART NUMBERS		
950-15710	950-17720	950-20720
950-15720	950-17726	950-25710
950-15726	950-17730	
950-15730	950-18720	

1. Install Street Scene Signal® Mirror assemblies to doors following mirror installation instruction.
2. Before beginning electrical hook - up check the operation of turn signals in the front and rear of vehicle. If any problem exist, repair before installing Street Scene Signal® Mirrors.
3. Run the Black / Red wire from the mirror into the door and into the rubber boot. Pull the rubber boot out between the door and door frame. Pass the wire harness into the vehicle by going through the opening located by the rubber boot. Run the wire to the left of the steering column. Do the same on the other side of truck. Re-install rubber boots.
4. The electrical wiring for the turn signal switch is located under the dash just below and left of the steering column. Locate the **GREEN WITH WHITE STRIPE** wire from within the wire bundle. Turn the ignition key so that the electrical power is on and activate the driver side turn signal. Probe the wire with the test light to verify that flashing turn signal power is present. Label that wire as "**Driver Side Turn**". Locate the **WHITE WITH BLUE STRIPE** wire within the wire bundle. Activate the passenger side turn signal and probe the wire with the test light to verify that flashing turn signal power is present. Label that wire as "**Passenger Side Turn**".
5. Make sure the harnesses are routed securely under the dash and enough slack is left for splicing.
6. Splice the **RED** wire from the passenger side harness into the **WHITE WITH BLUE STRIPE** wire previously labeled "**Passenger Side Turn**". Do not cut any wires when splicing.
7. Splice the **RED** wire from the driver side harness into the "**GREEN WITH WHITE STRIPE**" wire previously labeled "**Drivers Side Turn**".
8. Strip and twist together the ends of the black wires from each harness. Crimp them together in the supplied ring connector and ground to a suitable nearby location on the metal framework of the vehicle. A good ground location is located on the bare metal plate behind the hood release lever.
9. Activate each turn signal to verify that the Street Scene Signal® Mirrors are working.