



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

**CONNECTING
STREET SCENE
SIGNAL® MIRRORS
1993 - 2001
FORD RANGER**

CONNECTING STREET SCENE SIGNAL® MIRRORS

INSTRUCTIONS FOR PART NUMBERS		
950-15810	950-17820	950-25810
950-15820	950-18820	950-25820
950-15825	950-20820	

1. Install Street Scene Signal® Mirrors to doors following installation instructions.
2. Before beginning electrical hook-up, check the operation of turn signals in the front and rear of vehicle. If any problem exist, repair before installing Street Scene Signal® Mirrors.
3. Remove the door sill plates and kick panels.
4. Run the **RED / BLACK** wire on the mirror into the door. Pull out the rubber boot from the door and door frame. Guide the wire harness out of the hole vacated by the rubber boot.
5. Pull the rubber boot wire through the rubber boot and into the vehicle. Replace the rubber boot between the door and door frame.
6. Do the same on the passenger side. Run the wire across the dash past the steering column to the extreme left side of dash.
7. The electrical wiring for the Ford Ranger is located along the corner of the door frame. Roll over part of the carpeting along the door frame to expose the electrical wiring. Guide the wire harness from mirrors down to the wire bundle.
8. Locate the **GREEN WITH ORANGE STRIPE** wire from within the wire bundle. Turn the ignition key so that electrical power is on and activate the driver's side turn signal. Probe the wire with a test light to verify that flashing turn signal power is present. Label that wire as "**DRIVER'S SIDE TURN**".
9. Locate the **ORANGE WITH BLUE STRIPE** wire from within the wire bundle. Activate the passenger side turn signal and probe the wire with the test light to verify that flashing turn signal is present. Label that wire as "**PASSENGER SIDE TURN**".
10. Make sure the harnesses are routed securely to the vehicle's wire bundle and enough slack is left for splicing.
11. Splice the **RED** wire from the driver's side harness into the **GREEN WITH ORANGE STRIPE** wire previously labeled "**DRIVER'S SIDE TURN**".
12. Splice the **RED** wire from the passenger side harness into the **ORANGE WITH BLUE STRIPE** wire previously labeled "**PASSENGER SIDE TURN**". When splicing do not cut any wires. Use the quick splice connectors provided.
13. Strip and twist together the ends of the **BLACK** wires from both harness. Crimp them together in the supplied ring connector and ground to a suitable nearby location on the metal framework of the vehicle.
14. Activate each turn signal to verify that the Street Scene Signal® Mirrors are working properly.
15. Replace all trim pieces removed.