



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

**CONNECTING
STREET SCENE
SIGNAL® MIRRORS**
1999-2001 SILVERADO / SIERRA
2000-2001 SUBURBAN/YUKON/TAHOE

CONNECTING STREET SCENE SIGNAL® MIRRORS

INSTRUCTIONS FOR PART NUMBERS		
950-15910	950-19920	950-27920
950-15920	950-20920	950-27925
950-17925	950-25910	950-28920
950-17920	950-25920	950-28920
950-18920	950-26920	

1. Install Street scene Signal® Mirrors to doors following mirror installation instructions.
2. Before beginning electric hook-up, check the operation of turn signals in the front and rear of vehicle. If any problem exist repair before installing Street Scene Signal® mirrors.
3. Remove the door sill plates and kick panels.
4. Run the **RED / BLACK** harness wire from the mirror into the door. Pull out the rubber boot from the door and door frame. Guide the wire harness out of the hole vacated by the rubber boot.
5. Pull the rubber boot from the door frame. Guide the wire through the rubber boot and into the vehicle. Replace the rubber boot between the door and door frame.
6. Do the same on the passenger side. Run the wire across the dash to beneath the steering column.
7. The electrical wiring for the turn signals is located to the left of the steering column.
8. Locate the **LIGHT BLUE** wire from the wire bundle. Turn ignition key so that the electrical power is on activate the driver side turn signal. Probe the wire with the test light ti verify that flashing turn signal power is present. Label that wire as "**Drivers Side Turn**". Locate the **DARK BLUE** wire from within the wire bundle. Activate the passenger side turn signal and probe the wire with the test light to verify that flashing turn signal power is present. Label that wire as " Passenger Side Turn ".
9. Make sure the harnesses are routed securely under the dash and enough slack is left for splicing.
10. Splice the **RED** wire from the drivers side harness into the **LIGHT BLUE** wire previously labeled "**Drivers Side Turn**".
11. Splice the **RED** wire from the passenger side harness into the **DARK BLUE** wire previously labeled "**Passengers Side Turn**".
12. Strip and twist together the ends of the **BLACK** wires from each harness. Crimp them together in the supplied ring connector and ground to a suitable location on the metal framework of the vehicle.
13. Activate each turn signal to verify that the Street Scene Signal® Mirrors are working.

1/12/01 Connecting Street Scene Signal® Mirrors
1999 - 2001 Silverado / Sierra
2000 - 2001 Suburban / Yukon / Tahoe