



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, CA. 92626

Phone (714) 426-0590 Fax (714) 426-0591

950-27936

2007

CHEVY SILVERADO

AVALANCHE

TAHOE / SUBURBAN

GMC SIERRA / YUKON

YUKON XL

ELECTRIC MIRRORS

FACTORY HEATED

FACTORY SIGNAL

INSTALLATION INSTRUCTIONS

NOTE: Please check year, make, and model against application part number. Be sure both mirror heads and mounting plates are left & right side before painting. Parts that have been painted are not eligible for return.

NOTE: Do Not Use Loctite On Threads. Warranty Will Be Void If Used

NOTE: Do Not Attempt To Remove Glass For Paint Damage Could Occur And Glass Will Break.

NOTE: Do Not Over Tighten Nuts, Mounting Brackets Will Crack

NOTE: If Painting Mirrors Tape Over Threads To Keep Paint Off

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
2	Mirror Heads	1	Instruction Sheet	6	Six mm Nuts
2	Mirror Plates	1	Street Scene Decal	1	Care For Mirrors

TOOL LIST	
Door Panel Removal Tool, Small Flat Blade Screwdriver, 10MM Socket Or 10MM Wrench	

REMOVAL OF DOOR PANEL FOR AVALANCHE / TAHOE / SUBURBAN / YUKON / YUKON XL

1. Open Window
2. Remove the triangular panel behind the mirror by prying out the top side and then prying out and up at the bottom. A door panel removal tool works great for this.
3. Remove electric control panel on the arm rest and un-plug switches.
4. With the door lock in the " unlock " position pry out the small cover on the interior side of vehicle with a small screwdriver. Be careful not to misplace the cover. This will enable you to remove the manual lock button.
5. With a small screwdriver remove the plastic cover behind the door release handle. Remove the 10MM head bolt.
6. With a small screwdriver remove the plastic cover behind the door pull on the armrest. Remove the two 10MM head screws.
7. With a door panel removal tool pry out the door panel. Insert the tool at each location of the panel clips.
8. Lift up and remove door panel. NOTE: The door release handle cable will still be attached to the door panel. To remove cable gently pry out the cable housing. Be careful NOT TO DAMAGE the door panel when doing so. Rotate the cable housing 90 degrees away from door panel and slide the inner cable out of the handle. Set door panel in a safe place.
9. Pull back the upper corner of the moisture protector from the door below the mirror. It is not necessary to remove the entire cover.

10. Pry out the mirror wire loom retainers from door.
11. Remove the three nuts that secure the mirror to the door. Remove the gasket from mirror being careful not to tear. You will reuse the gasket on your Street Scene mirror.
12. Bolt the mirror plate to the mirror using the nuts provided tighten snugly. DO NOT over tighten.
13. Install the OEM gasket to mirror. Insert the wire loom into the hole in door and pull gently. Bolt mirror to door using the nuts removed in step 11.
14. Route the wire harness across the door as removed in step 10.
15. Install the door release cable to the back of door panel. Make sure to route the cable through the proper opening in the moisture protector.
16. " HOOK " the top lip of door panel to the door at the bottom of window opening. Make sure all wires are accessible to electrical panel opening.
17. Align all panel clips on door / panel to the holes in door. Snap into place.
18. Install all bolts and covers.
19. Plug in electrical panel and snap panel back into position.
20. Install all bolts, covers and door lock removed.

REMOVAL OF DOOR PANEL FOR A CHEVY SILVERADO / GMC SIERRA

1. Remove the cover of the vertical grab handle by prying out the bottom side with a small screwdriver on the slot. Remove the two 10 MM head bolts securing it to the door.
2. Remove the electrical control panel by pry up each end. Unplug all connections.
3. Remove the manual door lock cover by using a small screwdriver and prying up the small tab.
4. Pry up the small cover behind the door release handle and remove the 10 MM head bolt behind.
5. Pry out the small cover behind the arm rest and remove the two 10 MM head bolts.
6. Pry out the triangular cover behind the mirror on door.
7. Pop out the door panel from the door at the bottom and lift up to remove. NOTE: the door release cable will be attach.