



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, CA. 92626

Phone (714) 426-0590 Fax (714) 426-0591

950-60111

88 -98 Chevy, GM CK 3/4 Ton

1 Ton Ext. Cab, Crew Cab

& 1/2 Ton Long Bed

Roll Pan Hidden Hitch

INSTALLATION INSTRUCTIONS

**Do Not Exceed Lower
Of Towing Vehicle
Manufacturer's Ratings**

OR

Hitch Type	Max. Gross Trailer Weight (LBS)	Max. Tongue Weight (LBS)
Weight Carrying Ball Mount	5000	500

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

Note: No frame cutting or drilling needed.

If under bed spare tire is to be retained, then you will need to install SSE Part # 950-61110

Spare Tire Relocator.

Roll Pan cutting is required.

License plate must be repositioned when ball mount is being used (use SSE part # 61100

Flip License Kit or equivalent.

Parts List					
1	Receiver Assembly	6	1/2" Flat Washers	6	Heavy Duty Round Washers
6	1/2" X 1 1/2" Bolts	1	Instruction Sheet		
6	1/2" Nylock Nuts			1	Hitch Specification Label

Tool List	
1/2" Drive ratchet, 3/4" Socket, Torque Wrench, 3" Extension, 3/4" Combo Wrench, Safety Glasses.	

1. Before beginning installation be sure to wear proper eye protection.
2. Remove spare tire. If under bed spare tire is to be retained, a spare tire relocator will have to be installed (SSE Part # 950-61111)
3. Cut roll pan in license plate area to provide ball mount installation and pin clip access. Check location before cutting. **Note:** License plate **Must** be repositioned or a Flip License Kit (SSE # 950-61100) Installed while ball mount is in use.
4. Remove all fasteners from plastic bag and identify.
5. Position rear most slots in receiver over fore/aft slots near end of frame. Install the 1/2" X 2 1/4" by 1/4" heavy duty washers on the 1/2" X 3/4" bolts and set inside frame rail into receiver. Install flat washer and nut. Finger tighten only at this time.
6. Install all other fasteners in same manner in punched holes in frame into receiver.
7. Tighten all 1/2" GR5 fasteners installed to 75 ft. lbs. with torque wrench.
8. Affix load rating label in license plate area of roll pan.

Note: Check hitch frequently, making sure all fasteners and ball are properly tightened. If hitch is removed, replace all Ny-Lock nuts when re-installing. A hitch or ball which has been damaged should be removed and replaced. Observe safety precautions when working beneath a vehicle and wear eye protection. Follow vehicle manufacturer's specifications for maximum trailer weight and tongue weight.