



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue
 Costa Mesa, CA. 92626
 Phone (714) 426-0590 Fax (714) 426-0591

950-60122
 2007 - 2008
CHEVY SILVERADO
GMC SIERRA
SHORT BED STREET HITCH

INSTALLATION INSTRUCTIONS

**Do Not Exceed Lower
 Of Towing Vehicle
 Manufacturer's Ratings**

OR

Hitch Type	Max. Gross Trailer Weight (LBS)	Max. Tongue Weight (LBS)
Weight Carrying Ball Mount	5000	500

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

Note: Drilling Is Required

Parts List					
1	Receiver Assembly	1	Instruction Sheet	6	1/2" ID 1/4" Thick Washers
6	1/2" X 1 1/2" Bolts	6	1/2" Nyloc Nuts	1	Hitch Specification Label
6	1/2" ID Flat Washers	1	Street Scene Decal		

Tool List	
3/4" Wrench, 3/4" Socket, Extension, Ratchet, Torque Wench	

Install hitch prior to installing roll pan. It will be necessary to cut a receiver draw bar hole in roll pan. License plate will have to be re-positioned to gain access to hitch. Use Street Scene " Flip-Up " license kit P.N. 950-61100

1. Drop spare tire down.
2. Set hitch up to bottom of frame rails. Install the thick washers on to the bolt. Drop the bolt thru the inside of frame rail into the hole in hitch. Install the flat washer and nut. Install all six bolts and washers before tightening. Push the hitch forward toward the front of truck before tightening.
3. Torque all fasteners to 75 ft. lbs.
4. Crank up spare tire while pushing forward.