



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue
Costa Mesa, CA. 92626

Phone (714) 426-0590 Fax (714) 426-0591

950-60200
84 - 2004 GM S-10 / Sonoma
Roll Pan Street Hitch

INSTALLATION INSTRUCTIONS

**Do Not Exceed Lower
Of Towing Vehicle
Manufacturer's Ratings**

OR

| Hitch Type | Max. Gross Trailer Weight (LBS) | Max. Tongue Weight (LBS) |
|-------------------------------|--------------------------------------|-------------------------------|
| Weight Carrying Ball Mount | 5000 | 500 |

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

Note: No frame cutting or drilling needed.

Roll pan cutting is required.

License plate must be repositioned when ball mount is being used (use SSE part # 61100

Flip License Kit or equivalent.

| Parts List | | | | | |
|------------|----------------------|---|--------------------|---|---------------------------|
| 1 | Receiver Assembly | 6 | 7/16" Flat Washers | 6 | Heavy Duty Round Washers |
| 6 | 7/16" X 1 1/2" Bolts | 1 | Instruction Sheet | | |
| 6 | 7/16" Nylock Nuts | | | 1 | Hitch Specification Label |
| | | | | | |

| Tool List | |
|---|--|
| 1/2" Drive ratchet, 5/8" Socket, Torque Wrench, 3" Extension, 5/8" Combo Wrench, Safety Glasses. 13 mm. socket. | |

1. Before beginning installation be sure to wear proper eye protection.
2. Remove spare tire.
3. Cut roll pan in license plate area to provide ball mount installation and pin clip access. Check location before cutting. **Note:** License plate **Must** be repositioned or a Flip License Kit (SSE # 950-61100) Installed while ball mount is in use.
4. Remove all fasteners from plastic bag and identify.
5. Remove the 13 mm bolt securing tailpipe hanger on frame. Remove hanger from tailpipe.
6. Position hitch so that the three holes in hitch line up with the holes in frame. Install the six flat washers over the 7/16" - 18 X 1 3/4" bolt and insert through hitch and into frame.
7. Install the heavy washers and Ny-Lock nuts provided. Snug all bolts and align hitch.
8. Tighten all 7/16" GR5 fasteners installed to 65 FT. LBS. with torque wrench.
9. Slide tailpipe hanger removed in step 5, through hole in hitch slide plate and bolt back into place.
10. Attach tailpipe to hanger.