



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue
Costa Mesa, CA. 92626
Phone (714) 426-0590 Fax (714) 426-0591

950-60217
2004 - 2008
CHEVY COLORADO
&
GMC CANYON
ROLL PAN STREET HITCH

INSTALLATION INSTRUCTIONS

**Do Not Exceed Lower
Of Towing Vehicle
Manufacturer's Ratings**

OR

Hitch Type	Max. Gross Trailer Weight (LBS)	Max. Tongue Weight (LBS)
Weight Carrying Ball Mount	5000	500

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

Note: No frame cutting or drilling needed.

Roll pan cutting is required.

License plate must be repositioned when ball mount is being used (use SSE part # 61100

Flip License Kit or equivalent.

Parts List					
1	Receiver Assembly	1	Instruction Sheet	1	Hitch Specification Label
4	M-14 X 35 Bolts	2	1/2" X 1 1/2" Bolts		
4	9/16" Flat Washers	2	1/2" Flat Washers	2	1/2" Support Washers
4	9/16" Lock Washers	2	1/2" Lock Nuts		

Tool List	
1/2" Drive Ratchet, 3/4" & 7/8" Sockets, Torque Wrench, 3" Extension, 7/8" & 3/4" Combo Wrench, Safety Glasses	

1. Before beginning installation be sure to wear proper eye protection.
2. Remove spare tire.
3. Cut roll pan in license plate area to provide ball mount installation and pin clip access. Check location before cutting. **NOTE:** License plate **MUST** be repositioned. Or a flip up license kit (SSE # 950-61100) **Installed while ball mount is in use.**
4. Remove all fasteners from plastic bag and identify.
5. Position hitch so that the two holes on each side line up with the holes in frame. Install the 9/16" lock washers, 9/16" flat washers on the M-14 X 35 bolts and screw into frame. DO NOT tighten at this time.
6. Install the heavy support washers over the 1/2" bolts and insert through the bottom of frame. Install flat washers and lock nut in the inside of frame and tighten.
7. Tighten the side bolts and torque to 95 FT. LBS. Torque bottom bolts to 75 FT. LBS.
8. Re-install spare tire.