

## STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue Costa Mesa, CA. 92626 Phone (714) 426-0590 Fax (714) 426-0591 950-60715 2004 FORD F-150 STREET HITCH

## **INSTALLATION INSTRUCTIONS**

Do Not Exceed Lower
Of Towing Vehicle
Manufacturer's Ratings

OR

Hitch Type	Max. Gross Trailer Weight ( LBS )	Max. Tongue Weight ( LBS )	
Weight Carrying Ball Mount	5000	500	

**VERY IMPORTANT!** Read and understand all directions and check the following parts list before starting installation.

Note: No frame cutting or drilling needed.

Roll Pan cutting is required.

License plate must be repositioned when ball mount is being used ( use SSE part # 61100 Flip License Kit or equivalent.

Parts List					
1	Receiver Assembly	8	1/2" Flat Washers	4	1/2" Heavy Duty Washers
6	1/2" X 1 1/2" Bolts	1	Instruction Sheet		
6	1/2" Nylock Nuts			1	Hitch Specification Label

Tool List
3/4" Wrench, 3/4" Socket & Ratchet, Torque Wrench

- 1. Remove bumper.
- 2. Install hitch to bumper mounting brackets on frame. Install thin flat washers to all bolts and insert thru hitch and into frame. Use the four thick washers on the slotted holes in the backside of frame and the other two flat washers on the round holes. Install the nyloc nuts and torque to 75 LBS.