



## STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, CA. 92626

Phone (714) 426-0590 Fax (714) 426-0591

950-60716  
2006 - 2009  
FORD F-150  
1/2 TON  
STREET HITCH

### INSTALLATION INSTRUCTIONS

**Do Not Exceed Lower  
Of Towing Vehicle  
Manufacturer's Ratings**

OR

Hitch Type	Max. Gross Trailer Weight ( LBS )	Max. Tongue Weight ( LBS )
Weight Carrying Ball Mount	<b>5000</b>	<b>500</b>

**VERY IMPORTANT !** Read and understand all directions and check the following parts list before starting installation.

**NOTE: THIS HITCH FITS 2006 - 2007 MODELS ONLY FOR 2004 - 2005 MODELS USE PN 950-60715**

**Note: No frame cutting or drilling needed.**

**Roll Pan cutting is required.**

**License plate must be repositioned when ball mount is being used ( use SSE part # 61100**

**Flip License Kit or equivalent.**

Parts List					
1	Receiver Assembly	6	1/2" Flat Washers	6	1/2" Heavy Duty Washers
6	1/2" X 1 1/2" Bolts	1	Instruction Sheet		
6	1/2" Nylock Nuts			1	Hitch Specification Label

Tool List	
3/4" Wrench, 3/4" Socket & Ratchet, Torque Wrench	

1. Remove bumper. Install hitch prior to installing roll pan.
2. Remove spare tire.
3. Install hitch to frame at bumper mount flanges.
4. Install a flat washer on bolt and insert through the hitch and then through the frame. Install the thick washer on the back side and then the nyloc nut. Install all bolts and nuts and then tighten.
5. Torque all nuts 85 FT LBS.
6. Hoist up spare tire pushing it forward to clear hitch.

#### NOTE:

**Roll pan are available thru Street Scene Part Numbers 950-70710 Gen 1 and 950-70711 Gen 2**