



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, CA. 92626

Phone (714) 426-0590 Fax (714) 426-0591

950-60717

1999 - 2008

FORD SUPER DUTY

TOW HITCH

INSTALLATION INSTRUCTIONS

**Do Not Exceed Lower
Of Towing Vehicle
Manufacturer's Ratings**

OR

Hitch Type	Max. Gross Trailer Weight (LBS)	Max. Tongue Weight (LBS)
Weight Carrying Ball Mount	5000	500

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

This hitch must be used with a roll pan. Street Scene MFG. provides a roll pan P.N. 950-70845

Flip-up license plate kit available separately P.N. 950-61100

Parts List					
1	Hitch Assembly	1	Instruction Sheet	1	Street Scene Decal
1	Hitch Specification Label				
8	1 3/4" X 1 3/4" Support Washers (10109)				
8	9/16" X 1 3/4" Bolts (70556)				
8	9/16" Flat Washers (70916)				
8	9/16" Nyloc Nuts (79161)				

Tool List	
13/16" Wrench, 7/8" Socket, 6" Long Extension, 1/2" Drive Ratchet, Torque Wrench	

Insert the 9/16" X 1 3/4" bolts through the square heavy washer and into the holes in frame.

Set the hitch up into the bolts. Install the thin 9/16" flat washers and nyloc nut.

Snug all bolts up and align hitch so that it is square with frame.

Tighten all bolts to 90 FT LBS.

