



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

950-70104

2002 GMC ENVOY

&

2002 CHEV TRAIL BLAZER
WIPER COWL

INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting (See special instructions for paint Prep.) Parts that have been installed, prepped, or painted are not returnable.

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST

1	Wiper Cowl	1	Instruction Sheet	1	Fiberglass Paint Prep Sheet
6	Washer Head Screws	1	Street Scene Decal		

TOOL LIST

Miss. Tools, Drill Motor, Phillips Screwdriver, Safety Glasses, 5/32" Drill Bit, Masking Tape

1. Open hood. Mark location of hood to hood hinges. Disconnect engine compartment light from hood.
2. Remove antenna mast.
3. Remove hood.
4. Remove windshield wiper arms.
5. Remove factory wiper cowl while disconnecting windshield washer hose. Set hood seal aside. Remove windshield washers and install on the " Street Scene " smooth wiper cowl.
6. Install wiper cowl by inserting the passenger side at approximately a 45 degree angle under the fender ledge and over the antenna stud and then downward over the wiper studs to the driver's side.
7. Install the antenna mast.
8. Drill six 5/32 holes through wiper cowl and into cowl. Sandwich hood seal between wiper cowl and cowl and fasten with the screws provided.
9. Connect windshield washer hose.
10. Install hood using marks made in step 1 for alignment.
11. Re-fasten engine compartment light to hood.
12. Close hood and install wiper arms. Make sure placement of arms does not interfere with hood cowl.