



## STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

950-70106  
1982 - 1993  
GM "S" SERIES  
BUMPER COVER

### INSTALLATION INSTRUCTIONS

**VERY IMPORTANT !** Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Bumper Cover	1	Instruction Sheet	1	Urethane Prep Sheet
4	S/S Screws	1	Street Scene Decal		
6 FT.	Two Sided Tape 1/2"				

TOOL LIST	
Drill Motor, Drill Bits, Phillips Screwdriver	

**NOTE:** If bumper is equipped with a rubber impac strip, it must be removed before installing bumper cover.

1. Clean the top surface of bumper with alcohol. Clean the inner top side of bumper cover following prep instructions provided.
2. Apply the two sided tape to the top surface of bumper. Install bumper cover over bumper starting at one end and pulling over to opposite side. Reach in and remove the cover on the tape and pull to one side while applying pressure to top surface of bumper cover. NOTE: Bumper and bumper cover must be cleaned properly for a good tape adhesion.
3. Drill two holes on each end of bumper cover and into bumper. Install the screws provided.

5/30/02 SSE 950-70106