



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

INSTALLATION INSTRUCTIONS

950-70108

BUMPER

COVER / VALANCE

1988-1998

CHEVY / GMC / PICK-UP

1992-1999

TAHOE / SUBURBAN

NOTE: Fit all parts before painting (See special instructions for paint Prep.) Parts that have been installed, preped, or painted are not returnable.

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Bumper Cover / Valance	1	Instruction Sheet	4	S/S Sheet Metal Screws
		1	Street Scene Decal		

TOOL LIST	
Drill Motor, 5/32 Drill Bit, Phillips Head Screwdriver, Safety Glasses, 3/8" Drive Ratchet, 3/8" Drive Extension 10mm Wrench, 10mm socket	

1. Before beginning installation be sure to wear proper eye protection if drilling.
2. Remove the license plate holder from the front bumper, if so equipped, by removing the four bolts and nuts attaching it to the bumper. **NOTE:** you will not be able to re-install this on the bumper cover. If a front license plate has to be retained, go no further.
3. Remove the eleven 10mm head screws from the under side of the bumper securing the air deflector to the front bumper.
4. Remove the impact strip from the front bumper by removing the 10mm nuts at the right and left inside corners of the bumper.
5. Grasp the impact strip and pull to remove.
6. Starting at one corner, slip the bumper cover over the bumper and gently pull to the opposite side and snap over the bumper.
7. Using a 5/32 drill bit, drill through the bumper over and into the bumper at the right and left sides.
8. Attach with the 4 s/s screws supplied.
9. Paint to match follow urethane painting instructions.