



# STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue  
 Costa Mesa, CA. 92626  
 Phone (714) 426-0590 Fax (714) 426-0591

**950-70111**  
 1988-1998 GMC/CHEVY CK  
 1992-1999 CHEVY TAH/SUBUR  
 1992-1999 GMC YUKON/XL  
**SMOOTH WIPER COWL  
 WITHOUT WIPER HOLES**

## INSTALLATION INSTRUCTIONS

**NOTE: Fit all parts before painting (See special instructions for paint Prep.) Parts that have been installed, prepped, or painted are not returnable.**

**VERY IMPORTANT!** Read and understand all directions and check the following parts list before starting installation.

**Drilling Necessary      No Cutting Necessary**

**NOTE: NOT FOR STREET USE**

PARTS LIST					
<b>1</b>	Urethane Hood Cowl	<b>1</b>	Instruction Sheet	<b>6</b>	# 8 X 3/4" Washer Head Screws
				<b>2</b>	# 6 X 3/4" Sheet Metal Screws

TOOL LIST
Drill Motor, Phillips Screwdriver, Safety Glasses, 1/8" Drill Bit, Masking Tape, 13 mm Socket, 3/8" Ratchet, 3" Extension.

1. Before beginning installation be sure to wear proper eye protection.
2. Remove the windshield wipers.
3. Using masking tape, mark a reference point on the top of the right and left fenders, where the hood meets the existing cowl. This will help in placing the new hood cowl in the proper position.
4. Remove the hood. Mark location of hood before removing.
5. Remove the weather strip from across the top of the firewall.
6. Remove all 3 pieces of the existing hood cowl.
7. Remove the wiper arm mechanism from wiper motors.
8. Before fastening the new hood cowl into place, check for proper fit of both fenders, windshield and reference point on top of the fenders to the new hood cowl. Mount the hood cowl 1/4" from the hood.
9. To fasten the hood cowl, drill 1/8" hole through the cowl and into the inside fender flange. Install the 4 additional sheet metal screws through the cowl flange and the top of the firewall.
10. Replace the rubber waether strip across the top of the firewall.
11. To prevent the hood from striking the new hood cowl, trim the vertical pieces of the sheet metal on the underneath side of the hood. Check for proper clearance of mounting foot of the new hood cowl.
12. Re-install the hood.