



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

950-70112
HOOD COWL
1999 CHEVY SILVERADO
&
1999 GMC SIERRA

INSTALLATION INSTRUCTIONS

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Hood Cowl	1	Instruction Sheet	2	Attaching Clips # 71098
				3/4"	Two Sided Tape 68.5" Long

TOOL LIST	
13 MM Wrench Or Socket, # 15 Torx Socket, Flatblade Screwdriver	

1. Open hood.
2. Disconnect the windshield washer hoses from the wiper arms.
3. Remove the black nut covers over the wiper arm attaching nuts with a flat blade screwdriver and remove the 13mm nuts securing the wiper arms.
4. Close the hood. Lift wiper arms from windshield and gently pry arm from shaft. Note position of arm in reference to hood cowl. Also Note: There are R.H. and L.H. wiper arms. They are marked on the inside of arm.
5. Open hood. Gently pry off the R.H. and L.H. ends of the OEM hood cowl with a flat blade screwdriver. Under each end cap remove the # 15 Torx head screw found.
6. Remove the four push-on clips on the front edge of hood cowl. Save for installing new cowl.
7. Lift the drivers side of hood cowl up slightly and disconnect the washer line.
8. Remove hood cowl by lifting the passenger side up first and then lifting the driver's side up and out.
9. Remove the windshield washer hose and the hood seal on the OEM hood cowl. It will be necessary to first remove the hose elbows from the grommets.
10. Install the windshield washer hose on the Street Scene hood cowl and then install the hose elbows.
11. Wipe off the back side of the hood seal and install the pressure sensitive tape. Trim to fit. Install hood seal to hood cowl at the approximate location of OEM hood cowl.
12. Install the Street Scene hood cowl on truck by first installing the driver's side over the wiper arm shaft and following with the left side.
13. Reconnect washer hose to " T ". Make sure washer hose is resting in the tunnel in the hood cowl.
14. Re-install the four clips removed on the front edge of hood cowl. Install the two clips provided on the R.H. and L.H. sides of hood cowl.
15. Install wiper arms in their proper position and locations and secure with nuts and nut covers. Reconnect washer hoses to wiper arms.
16. Close hood and test windshield wipers and washers.