



## STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

950-70115  
 1999 - 2002  
**CHEVY SILVERADO**  
 &  
 2000 - 2004  
**SUBURBAN & TAHOE**  
**BUMPER COVER**

### INSTALLATION INSTRUCTIONS

**NOTE: Fit all parts before painting ( See Special Instructions For Paint Prep. ) Parts that have been installed, preped, or painted are not returnable.**

**VERY IMPORTANT !** Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Bumper Cover	1	Instruction Sheet	1	Street Scene Decal
4	S/S Screws	1	Urethane Prep Sheet		
6 FT.	3/4" Two Sided Tape				

TOOL LIST	
Phillips Screwdriver, Drill Motor, Drill Bits	

1. Remove the factory lower valance.
2. Clean the upper cap on bumper with a suitable cleaner to promote adhesion of tape.
3. Clean the top underside of bumper cover as you did to the upper cap.
4. Apply the two sided tape to the underside of the S/S Bumper Cover. Leave the backing on at this time.
5. Place the bumper cover over the front bumper.
6. Drill two holes on each side through bumper cover and into the steel bumper. Install the screws provided.
7. Remove the backing from the two sided tape and apply pressure to adhere the tape.