



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

950-70131

1988 - 1998

GM CK TRUCKS

TAHOES & SUBURBANS

REAR BUMPER COVER

FIBERGLASS

INSTALLATION INSTRUCTIONS

NOTE: THIS IS NOT A REPLACEMENT FOR THE REAR BUMPER

NOTE: Fit all parts before painting (See special instructions for paint Prep.) Parts that have been installed, prepped, or painted are not returnable.

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Rear Bumper Cover	1	Instruction Sheet		
2	1/2 " Flat Washers	1	Street Scene Decal		

TOOL LIST	
1/2" drive Ratchet, 3/4" Socket	

1. Remove the rubber step pad from bumper.
2. Remove the two bolts on the right and left ends on the under side of bumper.
3. Slip the bumper cover over the bumper.
4. Install the large washers supplied on the bolts removed in step II.
5. Install the bolts into the bumper cover and into the bumper where removed.