



## STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

**950-70139**  
**BUMPER**  
**COVER / VALANCE**  
**1985 - 1994**  
**ASTRO VAN**

### INSTALLATION INSTRUCTIONS

**NOTE:** Fit all parts before painting ( See special instructions for paint Prep. ) Parts that have been installed, preped, or painted are not returnable.

**VERY IMPORTANT !** Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Bumper Cover / Valance	1	Instruction Sheet	4	S/S Sheet Metal Screws
		1	Street Scene Decal		

TOOL LIST	
Drill Motor, Phillips Head Screwdriver, Safety Glasses, Drill Bit	

- 1 . Before beginning installation be sure to wear proper eye protection if drilling.
2. Remove front bumper OEM valance.
3. Install S/S Bumper Cover by installing on one end of bumper and working your way to the opposite side.
4. Drill two holes through Bumper Cover into bumper at each end and attach with screws provided.