



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

950-70141

1985 - 1994

CHEVY ASTRO VAN
FRONT SPOILER GEN 2

INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting (See Special Instructions For Paint Prep.) Parts that have been installed, preped, or painted are not returnable.

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	SS Valance	1	Instruction Sheet	1	Street Scene Decal
		1	Urethane Prep Sheet		

TOOL LIST	
10 MM Wrench Or Socket, Ratchet, Drill Motor, Drill Bits	

1. Remove the 10MM bolts securing the factory air deflector to the bumper. Save all attaching hardware.
2. Remove mounting fasteners from air deflector and save.
3. Place the OEM air deflector against the SS valance, mounting face to mounting face. Mark the location of the mounting holes. Drill holes and install fasteners removed in step 2.
4. Install the SS valance to bumper in the same manner as OEM air deflector.