



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue
Costa Mesa, Ca. 92626
Phone (714) 426-0590 Fax (714) 426-0591

950-70144
2003 - 04 GENERATION 1
CHEVY SILVERADO
BUMPER COVER / VALANCE

INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting (See Special Instructions For Paint Prep.) Parts that have been installed, preped, or painted are not returnable.

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Bumper Cover / Val	1	Instruction Sheet	1	Street Scene Decal
6 FT.	3/4" Two Sided Tape	1	Urethane Prep Sheet	4	Stainless Steel Screws

TOOL LIST	
Phillips Screwdriver, Flat Blade Screwdriver, 5/64 Drill Bit, Drill Motor	

1. Remove the fasteners retaining the OEM valance and remove.
2. Clean the top side of bumper cap with alcohol. Do the same on the inner side of bumper cover. Install the two sided tape to the top side of bumper cap. Remove the film on the top side.
3. Set one side of bumper cover over the edge of bumper and pull gently to the opposite side. Press the top side of bumper cover to bumper cap to adhere the tape.
4. Drill two holes on each side through bumper cover and into the steel bumper. Fasten with two screws per side.