



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue
Costa Mesa, Ca. 92626
Phone (714) 426-0590 Fax (714) 426-0591

950-70150
2004 - 2006
CHEVY SILVERADO HD
BUMPER COVER / VALANCE
URETHANE

INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting (See Special Instructions For Paint Prep.) Parts that have been installed, preped, or painted are not returnable.

NOTE:

USE STREET SCENE P.N. 950-7X143 SPEED GRILLE INSERTS

NOTE:

Check fit all body parts **PRIOR** to paint. Follow urethane prep instructions before painting. Take your time and pre-fit all pieces so that they will have a tight fit to the body.
VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Bumper Cover	1	Instruction Sheet	4	Stainless Steel Screws
		1	Urethane Prep Sheet	1	Street Scene Decal
				5 FT	1/2" Wide Two Sided Tape

TOOL LIST	
Drill Motor, 1/8" Drill Bit, Knife, Phillips Screwdriver,	

1. Remove the lower valance from bumper.
2. Clean the top side of the black ABS top pad on the bumper with alcohol. DO the same on the bottom side of the top of bumper cover.
3. Install the two sided tape on the top pad of bumper.
4. Install the Street Scene bumper cover by first hooking one corner on the bumper and then pulling around to the other side.
5. Drill two holes on each end through the bumper cover and into steel bumper. Fasten with the screws provided.