



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue
Costa Mesa, Ca. 92626
Phone (714) 426-0590 Fax (714) 426-0591

950-70153
2007
CHEVY TAHOE / SUBURBAN
BUMPER COVER
GENERATION 2

INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting (See Special Instructions For Paint Prep.) Parts that have been installed, preped, or painted are not returnable.

NOTE:

Check fit all body parts **PRIOR** to paint. Follow urethane prep instructions before painting. Take your time and pre-fit all pieces so that they will have a tight fit to the body.

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Bumper Cover	1	Instruction Sheet	10 FT	1/2" Wide Two Sided Tape
		1	Urethane Prep Sheet	1	Street Scene Decal
6	Washer Head Screws			2 PKS	Adhesion Promoter

TOOL LIST	
Ratchet, Extension, 10MM Socket, Drill Motor, 1/8" Drill Bit, Air Saw Or Die Grinder w / Cut Off Wheel	

1. Remove the OEM valance below the bumper cover by removing the fasteners at each end and unsnapping the ones between.
2. In each wheel well you will find four fasteners securing the inner splash shield to the bumper cover. Remove the two screws one at the top and one at the bottom and the two " Push In " fasteners between. Save fasteners.
3. Remove two " Push In " fasteners securing the top of the inner splash shield to the fender. Save fasteners.
4. Pull the inner splash shield down and back and loosen the two 10MM head bolts securing the bumper cover to the fender. They are located on the front fender going down into the bumper cover.
5. Mark " Cut Out " Outline on the OEM Bumper Cover. Refer to photo below. The area to be cut out will be the raised area in the center. **DO NOT** cut the bottom off.

PHOTO



6. Use an air saw and cut out the marked area.

PHOTO



PHOTO



7. When cuts are completed you will have an opening as shown in the photo below.

PHOTO



8. Clean the top side of the bumper cover and the under side of the top side of the Street Scene Bumper Cover. Apply the adhesion promoter to the under side of bumper cover and install the two sided tape. Wipe the top side of OEM bumper cover with the adhesion promoter also.
9. Hook one end of the Street Scene bumper cover over the corner of the bumper and pull over to the other end. Push cover in at sides between the fender and OEM bumper cover. Tighten screws loosen in step four.
10. Install all fasteners removed in steps two and three.
11. Install three screws in the Street Scene bumper cover into the OEM bumper cover at the wheel edge. Drill 1/8" holes before installing screws.