



## STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue  
Costa Mesa, Ca. 92626  
Phone (714) 426-0590 Fax (714) 426-0591

950-70154  
2007  
CHEVY TAHOE / SUBURBAN  
YUKON / XL  
WIPER COWL

### INSTALLATION INSTRUCTIONS

**NOTE: Fit all parts before painting ( See special instructions for paint Prep. ) Parts that have been installed, prepped, or painted are not returnable.**

**VERY IMPORTANT !** Read and understand all directions and check the following parts list before starting installation.

#### PRE FIT WIPER COWL BEFORE PAINTING

PARTS LIST					
1	Wiper Cowl	1	Instruction Sheet	1	Fiberglass Paint Prep Sheet
2	Washer Head Screws	1	Street Scene Decal	2	1/4" Push In Fasteners # 18379
				8	Installation Clips # 71098

TOOL LIST	
13MM Socket, 15MM Socket, Ratchet, Extension, Masking Tape, Phillips Screwdriver, Weather Strip Adhesive	

1. Disconnect gas shock from under side of hood.
2. Mark location of the hood hinges to under side of hood. Use masking tape to mark position. Remove hood.
3. Remove wiper arms by removing the 15MM nuts securing it.
4. Remove the OEM cowl by removing the phillips screws on each end and the clips across the front.
5. Remove the rubber seal on cowl.
6. Attach the rubber seal to the Street Scene wiper cowl using weather strip adhesive.
7. Install wiper cowl to vehicle and secure the ends with the fasteners provided. Secure the wiper cowl using the clips provided.
8. Install hood back on vehicle making sure it is aligned properly before closing.
9. Connect gas shock.