



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue
Costa Mesa, Ca. 92626
Phone (714) 426-0590 Fax (714) 426-0591

950-70158
2000 - 2004
CHEVY, SUBURBAN, TAHOE
GMC YUKON, YUKON XL
SMOOTH REAR VENT CAP
2 PIECE SET

INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting (See Special Instructions For Paint Prep.) Parts that have been installed, preped, or painted are not returnable.

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	RH Vent Cap	1	Instruction Sheet	4	Black Washer Head Screws
1	LH Vent Cap	1	Urethane Prep Sheet	1	Street Scene Decal

TOOL LIST	
Phillips Screwdriver, 5/32 Drill Bit, Drill Motor	

1. Open rear door. Remove the two fasteners securing the OEM vent cap on each side and remove the caps.
2. Drill two 5/32 holes on the smooth rear vent caps where marked.
3. Install the smooth vent caps by inserting the tabs into the opening and fasten the inside edge with the screws provided.
4. Paint to match.