



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

950-70161

GMC ENVOY

2002

FRONT VALANCE

INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting (See special instructions for paint Prep.) Parts that have been installed, prepped, or painted are not returnable.

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Front Valance	1	Urethane Prep Sheet	4	Black Washer Head Screws
1	Instruction Sheet	1	Street Scene Decal	8 FT.	1/2" Wide 2 Sided Tape

TOOL LIST	
Phillips Screwdriver	

NOTE: PRE-FIT BEFORE PAINTING

1. Clean the bottom side of bumper cover on truck following " Prep. Instruction ".
2. Clean the valance at the areas that you will be attaching the two sided tape.
3. Apply tape to the under side of center opening. Apply tape to the inside edges of valance at the right and left sides of center opening. **" DO NOT "** remove the backing at this time.
4. Set valance against bumper cover and lift one end of backing in the center and pull away while pressing valance against bumper cover. Do the same on the right and left sides.
5. At the front wheel well opening install two screws thru valance and into bumper. Do the same on opposite side.

NOTE: OTHER STREET SCENE BODY ENHANCEMENT KITS

SIDE SKIRT KIT PART # 950-70160

REAR SKIRT KIT PART # 950-70162