

STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue Costa Mesa, Ca. 92626 Phone (714) 426-0590 Fax (714) 426-0591

INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting (See Special Instructions For Paint Prep.) Parts that have been installed, preped, or painted are not returnable.

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST						
1	Front Valance	1	Instruction Sheet	1	Street Scene Decal	
		1	Urethane Prep Sheet			

TOOL LIST
Drill Motor, Drill Bits, Screwdriver's

- **1.** Remove the factory valance by reaching up under the valance and using a screwdriver turn the fasteners 1/4 turn CCW, SAVE ALL HARDWARE.
- 2. Set the Street Scene valance against bumper and align the front and sides. From the under side of front bumper mark the location of the mounting holes. Drill out.
- **3.** Using the fasteners removed in step 1 attach the valance to bumper.