



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue
Costa Mesa, Ca. 92626
Phone (714) 426-0590 Fax (714) 426-0591

950-70167
FRONT VALANCE
GM CK 88 - 98 TRUCKS
&
92 - 99 SUBURBAN & TAHOE
GEN 6

INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting (See Special Instructions For Paint Prep.) Parts that have been installed, preped, or painted are not returnable.

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Front Valance	1	Instruction Sheet	1	Urethane Paint Preparation Sheet
		1	Street Scene Decal		

TOOL LIST	
10 mm Socket, 3/8" Ratchet, Drill Motor, 2 - C Clamps (Helpful but not neccssary), 6" Extension, Small flat blade screwdriver, 1/4" Drill Bit, Safety Glasses	

- 1 . Before beginning installation be sure to wear proper eye protection if drilling.
2. Remove the nine 10 mm head screws securing the air deflector to the front bumper. Save all of the hardware.
3. Place the front valance under the front bumper and clamp at each end. Align the front valance with the bumper edges.
4. Using a 1/4 " drill bit , drill through the front valance and into the holes in the bumper where the original air deflector was attached.
5. Using the nine 6 mm bolts removed in step two, attach the new valance to the bumper.
6. Paint to match. Follow urethane parts surface preparation procedures.