



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue
Costa Mesa, Ca. 92626
Phone (714) 426-0590 Fax (714) 426-0591

950-70170
2007 - 2008
CHEVY SILVERDO
STD CAB
SIDE SKIRT SET
6 PC. URETHANE

INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting (See Special Instructions For Paint Prep.) Parts that have been installed, preped, or painted are not returnable.

NOTE:

Check fit all body parts **PRIOR** to paint. Follow urethane prep instructions before painting. Take your time and pre-fit all pieces so that they will have a tight fit to the body.

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
		1	Instruction Sheet	16 FT.	3/4" Two Sided Tape
1	Street Scene Decal	1	Urethane Prep Sheet	10 FT.	1/2" Two Sided Tape
18	Phillips Washerhead Screws # 71834			6 PKGS	Adhesion Promoter

TOOL LIST	
Drill Motor, 1/8" Drill Bit, Phillips Screwdriver, Razor Blade	

SIDE SKIRTS PARTS LIST			
1	RH Cab Side Skirt 005-70170CR	1	LH Bed Front Side Skirt 005-70186BL
1	LH Cab Side Skirt 005-70170CL	1	RH Bed Rear Side Skirt 005-70186RR
1	RH Bed Front Side Skirt 005-70186BR	1	LH Bed Rear Side Skirt 005-70186RL

1. Thoroughly clean all parts **INSIDE** and out before proceeding.
2. Identify all parts for their location. All parts are numbered on the back side. See the parts list above if needed.
3. Clean the tape apply area on the back side of each part. Wipe the area with the adhesion promoter. Install the 1/2" wide tape to all parts the will be attached to the bed. Install the 3/4" wide tape to the two long cab pieces. **DO NOT** remove the red backing at this time.
4. Wipe off the lower body of truck with a wax and grease remover.
5. Set each part on truck to locate. Remove part and apply automotive adhesion promoter 4298 to the area where the tape will contact the body.
6. Install each piece to the body by removing the backing and applying pressure to each piece.
7. From the under side of truck drill 1 hole in the front and rear of the skirt on the cab into the body. Secure skirt with the screws provided. Drill one hole through the skirt and into the wheel well and attach with provided screws.
8. The forward bed skirts will also be attached with screws in the under side into body and a screw at each end into the wheel well.
9. The rearward bed skirts will also be screwed into the wheel well opening.