



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

950-70185

1994 - 2004

CHEVY / GMC "S" SERIES

EXT. CAB SHORT BED

6 PS SIDE SKIRT KIT

INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting (See Special Instructions For Paint Prep.) Parts that have been installed, preped, or painted are not returnable.

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
6 PC.	Side Skirt Kit	1	Instruction Sheet	1	Street Scene Decal
25 FT.	1/2" Two Sided Tape	1	Urethane Prep Sheet		
22	Black Washer Head Self Drilling Screws				

TOOL LIST	
Drill Motor, 1/8" Drill Bit, Phillips Screwdriver, Razor Blade	

NOTE:

PARTS MUST BE CLEANED PROPERLY FOR THE TWO SIDED TAPE TO ADHERE PROPERLY

NOTE:

Side skirt panels are secured with two sided tape and screws. Follow instructions completely **DO NOT** eliminate any screws. Make sure all body areas and skirt tape areas are properly cleaned for good adhesion.

1. Remove entry plates at all door openings.
2. Remove the rock panels behind the rear well openings.
3. Apply the two sided tape to the top edges and the ends of the cab skirt panels. Position on cab and remove backing on two sided tape. Apply pressure to adhere tape. Drill a hole at each end of the panel that extends upward at the door openings. Install the self taping screws provided. Do the same at all door openings. At the front wheel well opening drill a hole through the skirt and into the wheel well lip. Fasten with the self taping screws provided. Fasten the rear of the side skirt by drilling a hole from the underneath side of skirt into the body and install the self taping screws provided.
4. Apply the two sided tape to the front bed skirt panels. Position on bed and remove backing. At the rear wheel opening drill a hole into the side skirt and into the wheel well lip. Fasten with the screws provided. Drill a hole from the inside of the bed flange down into the skirt from reaching in from the rear wheel opening. Secure with the screws provided. Do the same on the opposite side.
5. Apply the two sided tape to the rear bed skirt panels. Position on bed and remove backing. At the rear wheel opening drill two holes into the wheel well lip. Fasten with two screws. At the rear of the skirt panel drill a hole from the under side (where it cannot be seen) into the bed. Fasten with the screws provided. Do the same on the opposite side.