



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue
Costa Mesa, Ca. 92626
Phone (714) 426-0590 Fax (714) 426-0591

950-70188
2007
CHEVY / GMC
TAHOE / YUKON
SIDE SHIRT SET
URETHANE

INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting (See Special Instructions For Paint Prep.) Parts that have been installed, preped, or painted are not returnable.

NOTE:

Check fit all body parts PRIOR to paint. Follow urethane prep instructions before painting. Take your time and pre-fit all pieces so that they will have a tight fit to the body.

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	LT Side Shirt	1	Instruction Sheet	12 FT	1/2" Wide Two Sided Tape
1	RT Side Skirt	1	Urethane Prep Sheet	1	Street Scene Decal
10	# 10 Self Drilling Screws # 66126			3 PKGS	Adhesion Promoter

TOOL LIST	
Drill Motor, Phillips Screwdriver Bit, Scissors,	

1. Remove the side steps from vehicle.
2. Each side skirt is labeled on the back side for it's location.
3. Pre-fit side shirts prior to painting. When painting follow urethane paint preperation instructions.
4. Clean the tape apply area with alcohol.
5. Wipe the area with the supplied adhasion promoter and install the two sided tape.
6. Wipe the area that the tape will mate to on the vehicle with the adhesion promoter.
7. With the aid of another person set the side skirt up to the vehicle & remove the backing and apply pressure along the outer surface.
8. From the underside install five of the self drilling screws provided. Install one at each end, one in the center and center the two remaining between.