



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue
Costa Mesa, Ca. 92626
Phone (714) 426-0590 Fax (714) 426-0591

950-70196
2007
GMC SIERRA
FRONT BUMPER COVER
GENERATION 1
URETHANE

INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting (See Special Instructions For Paint Prep.) Parts that have been installed, preped, or painted are not returnable.

TEST FIT BEFORE PAINTING

NOTE:

Check fit all body parts PRIOR to paint. Follow urethane prep instructions before painting. Take your time and pre-fit all pieces so that they will have a tight fit to the body.

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

| PARTS LIST | | | | | |
|------------|--------------|---|---------------------|---|------------------------|
| 1 | Bumper Cover | 1 | Instruction Sheet | 4 | Stainless Steel Screws |
| | | 1 | Urethane Prep Sheet | 1 | Street Scene Decal |
| | | | | | |

| TOOL LIST | |
|--|--|
| Drill Motor, 3/8" Drill Bit, 7/32" Drill Bit, 11/64" Drill Bit, Phillips Screwdriver | |

1. Remove the factory lower valance from bumper.
2. Using a 3/8" diameter drill bit, drill the three dimpled marked holes in each light bucket on the Street Scene bumper cover.
3. Starting on one end hook the corner of the bumper cover to bumper and pull to the other side and hook over corner of bumper. Drill two holes through bumper cover and into bumper with a 11/64" drill bit. Enlarge the holes (In bumper cover ONLY) to 7/32". Install the stainless steel screws provided.
4. The lights will install from the back side. Use all mounting hardware from OEM valance.